

Remote Network Monitoring Management Information Base for High
Capacity Networks

Status of this Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2002). All Rights Reserved.

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in TCP/IP-based internets. In particular, it defines objects for managing remote network monitoring (RMON) devices for use on high speed networks. This document contains a MIB Module that defines these new objects and also contains definitions of some updated objects from the RMON-MIB in RFC 2819 and the RMON2-MIB in RFC 2021.

Table of Contents

1	The SNMP Management Framework	2
2	Overview	3
2.1	Structure of MIB	3
3	Updates to RMON MIB and RMON2 MIB objects	4
4	Conventions	6
5	Definitions	7
6	Security Considerations	73
7	Acknowledgments	73
8	References	73
9	Notices	75
10	Author's Address.....	76
11	Full Copyright Statement.....	77

1. The SNMP Management Framework

The SNMP Management Framework presently consists of five major components:

- o An overall architecture, described in RFC 2571 [1].
- o Mechanisms for describing and naming objects and events for the purpose of management. The first version of this Structure of Management Information (SMI) is called SMIV1 and described in STD 16, RFC 1155 [2], STD 16, RFC 1212 [3], and RFC 1215 [4]. The second version, called SMIV2, is described in STD 58, RFC 2578 [5], RFC 2579 [6], and RFC 2580 [7].
- o Message protocols for transferring management information. The first version of the SNMP message protocol is called SNMPv1 and is described in STD 15, RFC 1157 [8]. A second version of the SNMP message protocol, which is not an Internet standards track protocol, is called SNMPv2c and is described in RFC 1901 [9], and RFC 1906 [10]. The third version of the message protocol is called SNMPv3 and is described in RFC 1906 [10], RFC 2572 [11], and RFC 2574 [12].
- o Protocol operations for accessing management information. The first set of protocol operations and associated PDU formats is described in STD 15, RFC 1157 [8]. A second set of protocol operations and associated PDU formats is described in RFC 1905 [13].
- o A set of fundamental applications described in RFC 2573 [14] and the view-based access control mechanism described in RFC 2575 [15].

A more detailed introduction to the current SNMP Management Framework can be found in RFC 2570 [22].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. Objects in the MIB are defined using the mechanisms defined in the SMI.

This memo specifies a MIB module that is compliant to the SMIV2. A MIB conforming to the SMIV1 can be produced through the appropriate translations. The resulting translated MIB must be semantically equivalent, except where objects or events are omitted because no translation is possible (use of Counter64). Some machine readable information in SMIV2 will be converted into textual descriptions in

SMIv1 during the translation process. However, this loss of machine readable information is not considered to change the semantics of the MIB.

2. Overview

This document continues the architecture created in the RMON MIB [RFC 2819] by supporting high speed networks.

Remote network monitoring devices, often called monitors or probes, are instruments that exist for the purpose of managing a network. Often these remote probes are stand-alone devices and devote significant internal resources for the sole purpose of managing a network. An organization may employ many of these devices, one per network segment, to manage its internet. In addition, these devices may be used for a network management service provider to access a client network, often geographically remote.

The objects defined in this document are intended as an interface between an RMON agent and an RMON management application and are not intended for direct manipulation by humans. While some users may tolerate the direct display of some of these objects, few will tolerate the complexity of manually manipulating objects to accomplish row creation. These functions should be handled by the management application.

2.1 Structure of MIB

Except for the mediaIndependentTable, each of the tables in this MIB adds high capacity capability to an associated table in the RMON-1 MIB or RMON-2 MIB.

The objects are arranged into the following groups:

- mediaIndependentGroup
- etherStatsHighCapacityGroup
- etherHistoryHighCapacityGroup
- hostHighCapacityGroup
- hostTopNHighCapacityGroup
- matrixHighCapacityGroup
- captureBufferHighCapacityGroup

- protocolDistributionHighCapacityGroup
- nlHostHighCapacityGroup
- nlMatrixHighCapacityGroup
- nlMatrixTopNHighCapacityGroup
- alHostHighCapacityGroup
- alMatrixHighCapacityGroup
- alMatrixTopNHighCapacityGroup
- usrHistoryHighCapacityGroup

These groups are the basic units of conformance. If a remote monitoring device implements a group, then it must implement all objects in that group. For example, a managed agent that implements the network layer matrix group must implement the nlMatrixSDHighCapacityTable and the nlMatrixDSHighCapacityTable.

Implementations of this MIB must also implement the system and interfaces group of MIB-II [16,17]. MIB-II may also mandate the implementation of additional groups.

These groups are defined to provide a means of assigning object identifiers, and to provide a method for agent implementors to know which objects they must implement.

3. Updates to RMON MIB and RMON2 MIB objects

This document extends the enumerations in the following objects from the RMON MIB [18] and the RMON2 MIB [20].

From the RMON MIB:

hostTopNRateBase OBJECT-TYPE

```
SYNTAX      INTEGER {
    hostTopNInPkts(1),
    hostTopNOutPkts(2),
    hostTopNInOctets(3),
    hostTopNOutOctets(4),
    hostTopNOutErrors(5),
    hostTopNOutBroadcastPkts(6),
    hostTopNOutMulticastPkts(7),
    hostTopNHCInPkts(8),
    hostTopNHCOutPkts(9),
```

```

        hostTopNHCInOctets(10),
        hostTopNHCOctets(11)
    }
MAX-ACCESS read-create
STATUS current
DESCRIPTION
    "The variable for each host that the hostTopNRate
    variable is based upon, as well as a control
    for the table that the results will be reported in.

    This object may not be modified if the associated
    hostTopNStatus object is equal to valid(1).

    If this value is less than or equal to 7, when the report
    is prepared, entries are created in the hostTopNTable
    associated with this object.
    If this value is greater than or equal to 8, when the report
    is prepared, entries are created in the
    hostTopNHighCapacityTable associated with this object."
 ::= { hostTopNControlEntry 3 }

```

From the RMON2 MIB:

```

nlMatrixTopNControlRateBase OBJECT-TYPE
    SYNTAX      INTEGER {
        nlMatrixTopNPkts(1),
        nlMatrixTopNOctets(2),
        nlMatrixTopNHighCapacityPkts(3),
        nlMatrixTopNHighCapacityOctets(4)
    }
MAX-ACCESS read-create
STATUS current
DESCRIPTION
    "The variable for each nlMatrix[SD/DS] entry that the
    nlMatrixTopNEntries are sorted by, as well as a control
    for the table that the results will be reported in.

    This object may not be modified if the associated
    nlMatrixTopNControlStatus object is equal to active(1).

    If this value is less than or equal to 2, when the report
    is prepared, entries are created in the nlMatrixTopNTable
    associated with this object.
    If this value is greater than or equal to 3, when the report
    is prepared, entries are created in the
    nlMatrixTopNHighCapacityTable associated with this object."
 ::= { nlMatrixTopNControlEntry 3 }

```

From the RMON2 MIB:

alMatrixTopNControlRateBase OBJECT-TYPE

```
SYNTAX      INTEGER {
                alMatrixTopNTerminalsPkts(1),
                alMatrixTopNTerminalsOctets(2),
                alMatrixTopNAllPkts(3),
                alMatrixTopNAllOctets(4),
                alMatrixTopNTerminalsHighCapacityPkts(5),
                alMatrixTopNTerminalsHighCapacityOctets(6),
                alMatrixTopNAllHighCapacityPkts(7),
                alMatrixTopNAllHighCapacityOctets(8)
            }
```

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"The variable for each alMatrix[SD/DS] entry that the alMatrixTopNEntries are sorted by, as well as the selector of the view of the matrix table that will be used, as well as a control for the table that the results will be reported in.

The values alMatrixTopNTerminalsPkts, alMatrixTopNTerminalsOctets, alMatrixTopNTerminalsHighCapacityPkts, and alMatrixTopNTerminalsHighCapacityOctets cause collection only from protocols that have no child protocols that are counted. The values alMatrixTopNAllPkts, alMatrixTopNAllOctets, alMatrixTopNAllHighCapacityPkts, and alMatrixTopNAllHighCapacityOctets cause collection from all alMatrix entries.

This object may not be modified if the associated alMatrixTopNControlStatus object is equal to active(1)."

::= { alMatrixTopNControlEntry 3 }

For convenience, updated MIB modules containing these objects may be found at:

<ftp://ftp.rfc-editor.org/in-notes/mibs/current.mibs/rmon.mib>
<ftp://ftp.rfc-editor.org/in-notes/mibs/current.mibs/rmon2.mib>

4. Conventions

The following conventions are used throughout the RMON MIB and its companion documents.

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in RFC 2119.

Good Packets

Good packets are error-free packets that have a valid frame length. For example, on Ethernet, good packets are error-free packets that are between 64 octets long and 1518 octets long. They follow the form defined in IEEE 802.3 section 3.2.all. Implementors are urged to consult the appropriate media-specific specifications.

Bad Packets

Bad packets are packets that have proper framing and are therefore recognized as packets, but contain errors within the packet or have an invalid length. For example, on Ethernet, bad packets have a valid preamble and SFD (Start of Frame Delimiter), but have a bad FCS (Frame Check Sequence), or are either shorter than 64 octets or longer than 1518 octets. Implementors are urged to consult the appropriate media-specific specifications.

5. Definitions

HC-RMON-MIB DEFINITIONS ::= BEGIN

IMPORTS

```

    MODULE-IDENTITY, OBJECT-TYPE, Counter32, Integer32,
        Gauge32, Counter64                FROM SNMPv2-SMI
    RowStatus, TimeStamp                  FROM SNMPv2-TC
    MODULE-COMPLIANCE, OBJECT-GROUP FROM SNMPv2-CONF
    rmon, OwnerString, statistics, history, hosts, hostTopN, matrix,
    etherStatsIndex, etherHistoryIndex, etherHistorySampleIndex,
    hostIndex, hostAddress, hostTimeIndex, hostTimeCreationOrder,
    hostTopNReport, hostTopNIndex,
    matrixSDIndex, matrixSDSourceAddress, matrixSDDestAddress,
    matrixDSIndex, matrixDSDestAddress, matrixDSSourceAddress,
    capture, captureBufferControlIndex, captureBufferIndex
                                FROM RMON-MIB
    protocolDirLocalIndex, protocolDistControlIndex,
    protocolDist, hlHostControlIndex,
    nlHost, nlHostTimeMark, nlHostAddress,
    hlMatrixControlIndex, nlMatrix,
    nlMatrixSDTimeMark, nlMatrixSDSourceAddress, nlMatrixSDDestAddress,
    nlMatrixDSTimeMark, nlMatrixDSDestAddress, nlMatrixDSSourceAddress,
    nlMatrixTopNControlIndex, nlMatrixTopNIndex,
    alHost, alHostTimeMark,
    alMatrix, alMatrixSDTimeMark, alMatrixDSTimeMark,
    alMatrixTopNControlIndex, alMatrixTopNIndex,

```

```

usrHistory, usrHistoryControlIndex,
usrHistorySampleIndex, usrHistoryObjectIndex,
rmonConformance, ZeroBasedCounter32, probeConfig
                                FROM RMON2-MIB
ZeroBasedCounter64, CounterBasedGauge64
                                FROM HCNUM-TC;

```

-- Remote Network Monitoring MIB

hCRMON MODULE-IDENTITY

LAST-UPDATED "200205080000Z" -- May 08, 2002

ORGANIZATION "IETF RMON MIB Working Group"

CONTACT-INFO

"Steve Waldbusser

Phone: +1-650-948-6500

Fax: +1-650-745-0671

Email: waldbusser@nextbeacon.com

Andy Bierman

WG Chair

abierman@cisco.com

RMONMIB WG Mailing List

rmonmib@ietf.org

<http://www.ietf.org/mailman/listinfo/rmonmib>"

DESCRIPTION

"The MIB module for managing remote monitoring device implementations. This MIB module augments the original RMON MIB as specified in RFC 2819 and RFC 1513 and RMON-2 MIB as specified in RFC 2021."

REVISION "200205080000Z" -- May 08, 2002

DESCRIPTION

"The original version of this MIB, published as RFC3273."

::= { rmonConformance 5 }

-- { rmon 1 } through { rmon 20 } are defined in RMON [RFC 2819] and
 -- the Token Ring RMON MIB [RFC 1513] and the RMON-2 MIB [RFC 2021].

mediaIndependentStats OBJECT IDENTIFIER ::= { rmon 21 }

mediaIndependentTable OBJECT-TYPE

SYNTAX SEQUENCE OF MediaIndependentEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Media independent statistics for promiscuous monitoring of any media.

The following table defines media independent statistics that provide information for full and/or half-duplex links as well as high capacity links.

For half-duplex links, or full-duplex-capable links operating in half-duplex mode, the mediaIndependentIn* objects shall be used and the mediaIndependentOut* objects shall not increment.

For full-duplex links, the mediaIndependentOut* objects shall be present and shall increment. Whenever possible, the probe should count packets moving away from the closest terminating equipment as output packets. Failing that, the probe should count packets moving away from the DTE as output packets."

```
::= { mediaIndependentStats 1 }
```

mediaIndependentEntry OBJECT-TYPE

SYNTAX MediaIndependentEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Media independent statistics for promiscuous monitoring of any media."

INDEX { mediaIndependentIndex }

```
::= { mediaIndependentTable 1 }
```

MediaIndependentEntry ::= SEQUENCE {

mediaIndependentIndex	Integer32,
mediaIndependentDataSource	OBJECT IDENTIFIER,
mediaIndependentDropEvents	Counter32,
mediaIndependentDroppedFrames	Counter32,
mediaIndependentInPkts	Counter32,
mediaIndependentInOverflowPkts	Counter32,
mediaIndependentInHighCapacityPkts	Counter64,
mediaIndependentOutPkts	Counter32,
mediaIndependentOutOverflowPkts	Counter32,
mediaIndependentOutHighCapacityPkts	Counter64,
mediaIndependentInOctets	Counter32,
mediaIndependentInOverflowOctets	Counter32,
mediaIndependentInHighCapacityOctets	Counter64,
mediaIndependentOutOctets	Counter32,
mediaIndependentOutOverflowOctets	Counter32,
mediaIndependentOutHighCapacityOctets	Counter64,
mediaIndependentInNUCastPkts	Counter32,
mediaIndependentInNUCastOverflowPkts	Counter32,

```

mediaIndependentInNUCastHighCapacityPkts    Counter64,
mediaIndependentOutNUCastPkts                Counter32,
mediaIndependentOutNUCastOverflowPkts        Counter32,
mediaIndependentOutNUCastHighCapacityPkts    Counter64,
mediaIndependentInErrors                      Counter32,
mediaIndependentOutErrors                    Counter32,
mediaIndependentInputSpeed                   Gauge32,
mediaIndependentOutputSpeed                  Gauge32,
mediaIndependentDuplexMode                    INTEGER,
mediaIndependentDuplexChanges                 Counter32,
mediaIndependentDuplexLastChange              TimeStamp,
mediaIndependentOwner                         OwnerString,
mediaIndependentStatus                        RowStatus
}

mediaIndependentIndex OBJECT-TYPE
    SYNTAX      Integer32 (1..65535)
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "The value of this object uniquely identifies this
         mediaIndependent entry."
    ::= { mediaIndependentEntry 1 }

mediaIndependentDataSource OBJECT-TYPE
    SYNTAX      OBJECT IDENTIFIER
    MAX-ACCESS  read-create
    STATUS      current
    DESCRIPTION
        "This object identifies the source of the data that
         this mediaIndependent entry is configured to analyze.  This
         source can be any interface on this device.
         In order to identify a particular interface, this
         object shall identify the instance of the ifIndex
         object, defined in RFC 1213 and RFC 2233 [16,17], for
         the desired interface.  For example, if an entry
         were to receive data from interface #1, this object
         would be set to ifIndex.1.

         The statistics in this group reflect all packets
         on the local network segment attached to the
         identified interface.

         An agent may or may not be able to tell if
         fundamental changes to the media of the interface
         have occurred and necessitate a deletion of
         this entry.  For example, a hot-pluggable ethernet
         card could be pulled out and replaced by a

```

token-ring card. In such a case, if the agent has such knowledge of the change, it is recommended that it delete this entry.

This object may not be modified if the associated mediaIndependentStatus object is equal to active(1)."
::= { mediaIndependentEntry 2 }

mediaIndependentDropEvents OBJECT-TYPE

SYNTAX Counter32
UNITS "Events"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The total number of events in which packets were dropped by the probe due to lack of resources. Note that this number is not necessarily the number of packets dropped; it is just the number of times this condition has been detected."
::= { mediaIndependentEntry 3 }

mediaIndependentDroppedFrames OBJECT-TYPE

SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The total number of frames which were received by the probe and therefore not accounted for in the mediaIndependentDropEvents, but for which the probe chose not to count for this entry for whatever reason. Most often, this event occurs when the probe is out of some resources and decides to shed load from this collection.

This count does not include packets that were not counted because they had MAC-layer errors.

Note that, unlike the dropEvents counter, this number is the exact number of frames dropped."
::= { mediaIndependentEntry 4 }

mediaIndependentInPkts OBJECT-TYPE

SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The total number of packets (including bad packets,

broadcast packets, and multicast packets) received on a half-duplex link or on the inbound connection of a full-duplex link."

::= { mediaIndependentEntry 5 }

mediaIndependentInOverflowPkts OBJECT-TYPE

SYNTAX Counter32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated mediaIndependentInPkts counter has overflowed."

::= { mediaIndependentEntry 6 }

mediaIndependentInHighCapacityPkts OBJECT-TYPE

SYNTAX Counter64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of packets (including bad packets, broadcast packets, and multicast packets) received on a half-duplex link or on the inbound connection of a full-duplex link."

::= { mediaIndependentEntry 7 }

mediaIndependentOutPkts OBJECT-TYPE

SYNTAX Counter32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of packets (including bad packets, broadcast packets, and multicast packets) received on a full-duplex link in the direction of the network."

::= { mediaIndependentEntry 8 }

mediaIndependentOutOverflowPkts OBJECT-TYPE

SYNTAX Counter32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated mediaIndependentOutPkts counter has overflowed."

::= { mediaIndependentEntry 9 }

mediaIndependentOutHighCapacityPkts OBJECT-TYPE

SYNTAX Counter64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of packets (including bad packets, broadcast packets, and multicast packets) received on a full-duplex link in the direction of the network."

::= { mediaIndependentEntry 10 }

mediaIndependentInOctets OBJECT-TYPE

SYNTAX Counter32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of octets of data (including those in bad packets) received (excluding framing bits but including FCS octets) on a half-duplex link or on the inbound connection of a full-duplex link."

::= { mediaIndependentEntry 11 }

mediaIndependentInOverflowOctets OBJECT-TYPE

SYNTAX Counter32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated mediaIndependentInOctets counter has overflowed."

::= { mediaIndependentEntry 12 }

mediaIndependentInHighCapacityOctets OBJECT-TYPE

SYNTAX Counter64

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of octets of data (including those in bad packets) received (excluding framing bits but including FCS octets) on a half-duplex link or on the inbound connection of a full-duplex link."

::= { mediaIndependentEntry 13 }

mediaIndependentOutOctets OBJECT-TYPE

SYNTAX Counter32

UNITS "Octets"

MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The total number of octets of data (including those in bad
 packets) received on a full-duplex link in the direction of
 the network (excluding framing bits but including FCS
 octets)."
 ::= { mediaIndependentEntry 14 }

mediaIndependentOutOverflowOctets OBJECT-TYPE
SYNTAX Counter32
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of times the associated
 mediaIndependentOutOctets counter has overflowed."
 ::= { mediaIndependentEntry 15 }

mediaIndependentOutHighCapacityOctets OBJECT-TYPE
SYNTAX Counter64
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The total number of octets of data (including those in bad
 packets) received on a full-duplex link in the direction of
 the network (excluding framing bits but including FCS
 octets)."
 ::= { mediaIndependentEntry 16 }

mediaIndependentInNUCastPkts OBJECT-TYPE
SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The total number of non-unicast packets (including bad
 packets) received on a half-duplex link or on the inbound
 connection of a full-duplex link."
 ::= { mediaIndependentEntry 17 }

mediaIndependentInNUCastOverflowPkts OBJECT-TYPE
SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The number of times the associated
mediaIndependentInNUCastPkts counter has overflowed."
::= { mediaIndependentEntry 18 }

mediaIndependentInNUCastHighCapacityPkts OBJECT-TYPE

SYNTAX Counter64
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The total number of non-unicast packets (including bad
packets) received on a half-duplex link or on the inbound
connection of a full-duplex link."
::= { mediaIndependentEntry 19 }

mediaIndependentOutNUCastPkts OBJECT-TYPE

SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The total number of non-unicast packets (including bad
packets) received on a full-duplex link in the direction of
the network."
::= { mediaIndependentEntry 20 }

mediaIndependentOutNUCastOverflowPkts OBJECT-TYPE

SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of times the associated
mediaIndependentOutNUCastPkts counter has overflowed."
::= { mediaIndependentEntry 21 }

mediaIndependentOutNUCastHighCapacityPkts OBJECT-TYPE

SYNTAX Counter64
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The total number of packets (including bad packets)
received on a full-duplex link in the direction of the
network."
::= { mediaIndependentEntry 22 }

mediaIndependentInErrors OBJECT-TYPE

SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The total number of bad packets received on a
 half-duplex link or on the inbound connection of a
 full-duplex link."
::= { mediaIndependentEntry 23 }

mediaIndependentOutErrors OBJECT-TYPE

SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The total number of bad packets received on a full-duplex
 link in the direction of the network."
::= { mediaIndependentEntry 24 }

mediaIndependentInputSpeed OBJECT-TYPE

SYNTAX Gauge32
UNITS "Kilobits per Second"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The nominal maximum speed in kilobits per second of this
 half-duplex link or on the inbound connection of this
 full-duplex link. If the speed is unknown or there is no fixed
 maximum (e.g. a compressed link), this value shall be zero."
::= { mediaIndependentEntry 25 }

mediaIndependentOutputSpeed OBJECT-TYPE

SYNTAX Gauge32
UNITS "Kilobits per Second"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The nominal maximum speed in kilobits per second of this
 full-duplex link in the direction of the network. If the speed
 is unknown, the link is half-duplex, or there is no fixed
 maximum (e.g. a compressed link), this value shall be zero."
::= { mediaIndependentEntry 26 }

mediaIndependentDuplexMode OBJECT-TYPE

SYNTAX INTEGER {
 halfduplex(1),
 fullduplex(2)


```
    }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The current mode of this link.
```

Note that if the link has full-duplex capabilities but is operating in half-duplex mode, this value will be halfduplex(1)."

```
::= { mediaIndependentEntry 27 }
```

mediaIndependentDuplexChanges OBJECT-TYPE

```
SYNTAX Counter32
UNITS "Events"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
    "The number of times this link has changed from full-duplex
    mode to half-duplex mode or from half-duplex mode to
    full-duplex mode."
::= { mediaIndependentEntry 28 }
```

mediaIndependentDuplexLastChange OBJECT-TYPE

```
SYNTAX TimeStamp
MAX-ACCESS read-only
STATUS current
DESCRIPTION
    "The value of sysUpTime at the time the duplex status
    of this link last changed."
::= { mediaIndependentEntry 29 }
```

mediaIndependentOwner OBJECT-TYPE

```
SYNTAX OwnerString
MAX-ACCESS read-create
STATUS current
DESCRIPTION
    "The entity that configured this entry and is
    therefore using the resources assigned to it."
::= { mediaIndependentEntry 30 }
```

mediaIndependentStatus OBJECT-TYPE

```
SYNTAX RowStatus
MAX-ACCESS read-create
STATUS current
DESCRIPTION
    "The status of this media independent statistics entry."
::= { mediaIndependentEntry 31 }
```

-- High Capacity extensions for the etherStatsTable

etherStatsHighCapacityTable OBJECT-TYPE

```

SYNTAX      SEQUENCE OF EtherStatsHighCapacityEntry
MAX-ACCESS  not-accessible
STATUS      current
DESCRIPTION
    "Contains the High Capacity RMON extensions to the RMON-1
    etherStatsTable."
 ::= { statistics 7 }

```

etherStatsHighCapacityEntry OBJECT-TYPE

```

SYNTAX      EtherStatsHighCapacityEntry
MAX-ACCESS  not-accessible
STATUS      current
DESCRIPTION
    "Contains the High Capacity RMON extensions to the RMON-1
    etherStatsEntry. These objects will be created by the agent
    for all etherStatsEntries it deems appropriate."
INDEX { etherStatsIndex }
 ::= { etherStatsHighCapacityTable 1 }

```

```

EtherStatsHighCapacityEntry ::= SEQUENCE {
    etherStatsHighCapacityOverflowPkts          Counter32,
    etherStatsHighCapacityPkts                  Counter64,
    etherStatsHighCapacityOverflowOctets         Counter32,
    etherStatsHighCapacityOctets                Counter64,
    etherStatsHighCapacityOverflowPkts64Octets   Counter32,
    etherStatsHighCapacityPkts64Octets           Counter64,
    etherStatsHighCapacityOverflowPkts65to127Octets Counter32,
    etherStatsHighCapacityPkts65to127Octets      Counter64,
    etherStatsHighCapacityOverflowPkts128to255Octets Counter32,
    etherStatsHighCapacityPkts128to255Octets      Counter64,
    etherStatsHighCapacityOverflowPkts256to511Octets Counter32,
    etherStatsHighCapacityPkts256to511Octets      Counter64,
    etherStatsHighCapacityOverflowPkts512to1023Octets Counter32,
    etherStatsHighCapacityPkts512to1023Octets      Counter64,
    etherStatsHighCapacityOverflowPkts1024to1518Octets Counter32,
    etherStatsHighCapacityPkts1024to1518Octets      Counter64
}

```

etherStatsHighCapacityOverflowPkts OBJECT-TYPE

```

SYNTAX      Counter32
UNITS       "Packets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION

```

```
    "The number of times the associated etherStatsPkts
    counter has overflowed."
 ::= { etherStatsHighCapacityEntry 1 }
```

etherStatsHighCapacityPkts OBJECT-TYPE

```
SYNTAX      Counter64
UNITS       "Packets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "The total number of packets (including bad packets,
    broadcast packets, and multicast packets) received."
 ::= { etherStatsHighCapacityEntry 2 }
```

etherStatsHighCapacityOverflowOctets OBJECT-TYPE

```
SYNTAX      Counter32
UNITS       "Octets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "The number of times the associated etherStatsOctets
    counter has overflowed."
 ::= { etherStatsHighCapacityEntry 3 }
```

etherStatsHighCapacityOctets OBJECT-TYPE

```
SYNTAX      Counter64
UNITS       "Octets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "The total number of octets of data (including
    those in bad packets) received on the
    network (excluding framing bits but including
    FCS octets).
```

If the network is half-duplex Fast Ethernet, this object can be used as a reasonable estimate of utilization. If greater precision is desired, the etherStatsHighCapacityPkts and etherStatsHighCapacityOctets objects should be sampled before and after a common interval. The differences in the sampled values are Pkts and Octets, respectively, and the number of seconds in the interval is Interval. These values are used to calculate the Utilization as follows:

$$\text{Utilization} = \frac{\text{Pkts} * (.96 + .64) + (\text{Octets} * .08)}{\text{Interval} * 10,000}$$

The result of this equation is the value Utilization which is the percent utilization of the ethernet segment on a scale of 0 to 100 percent.

This table is not appropriate for monitoring full-duplex ethernets. If the network is a full-duplex ethernet and the mediaIndependentTable is monitoring that network, the utilization can be calculated as follows:

- 1) Determine the utilization of the inbound path by using the appropriate equation (for ethernet or fast ethernet) to determine the utilization, substituting mediaIndependentInPkts for etherStatsHighCapacityPkts, and mediaIndependentInOctets for etherStatsHighCapacityOctets. Call the resulting utilization inUtilization.
- 2) Determine the utilization of the outbound path by using the same equation to determine the utilization, substituting mediaIndependentOutPkts for etherStatsHighCapacityPkts, and mediaIndependentOutOctets for etherStatsHighCapacityOctets. Call the resulting utilization outUtilization.
- 3) The utilization is the maximum of inUtilization and outUtilization. This metric shows the amount of percentage of bandwidth that is left before congestion will be experienced on the link."

::= { etherStatsHighCapacityEntry 4 }

etherStatsHighCapacityOverflowPkts64Octets OBJECT-TYPE

SYNTAX Counter32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated etherStatsPkts64Octets counter has overflowed."

::= { etherStatsHighCapacityEntry 5 }

etherStatsHighCapacityPkts64Octets OBJECT-TYPE

SYNTAX Counter64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

```
    "The total number of packets (including bad
    packets) received that were 64 octets in length
    (excluding framing bits but including FCS octets)."
```

::= { etherStatsHighCapacityEntry 6 }

etherStatsHighCapacityOverflowPkts65to127Octets OBJECT-TYPE

```
SYNTAX      Counter32
UNITS       "Packets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "The number of times the associated etherStatsPkts65to127Octets
    counter has overflowed."
```

::= { etherStatsHighCapacityEntry 7 }

etherStatsHighCapacityPkts65to127Octets OBJECT-TYPE

```
SYNTAX      Counter64
UNITS       "Packets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "The total number of packets (including bad
    packets) received that were between
    65 and 127 octets in length inclusive
    (excluding framing bits but including FCS octets)."
```

::= { etherStatsHighCapacityEntry 8 }

etherStatsHighCapacityOverflowPkts128to255Octets OBJECT-TYPE

```
SYNTAX      Counter32
UNITS       "Packets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "The number of times the associated etherStatsPkts128to255Octets
    counter has overflowed."
```

::= { etherStatsHighCapacityEntry 9 }

etherStatsHighCapacityPkts128to255Octets OBJECT-TYPE

```
SYNTAX      Counter64
UNITS       "Packets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "The total number of packets (including bad
    packets) received that were between
    128 and 255 octets in length inclusive
    (excluding framing bits but including FCS octets)."
```

::= { etherStatsHighCapacityEntry 10 }

etherStatsHighCapacityOverflowPkts256to511Octets OBJECT-TYPE

SYNTAX Counter32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated etherStatsPkts256to511Octets counter has overflowed."

::= { etherStatsHighCapacityEntry 11 }

etherStatsHighCapacityPkts256to511Octets OBJECT-TYPE

SYNTAX Counter64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets)."

::= { etherStatsHighCapacityEntry 12 }

etherStatsHighCapacityOverflowPkts512to1023Octets OBJECT-TYPE

SYNTAX Counter32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated etherStatsPkts512to1023Octets counter has overflowed."

::= { etherStatsHighCapacityEntry 13 }

etherStatsHighCapacityPkts512to1023Octets OBJECT-TYPE

SYNTAX Counter64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets)."

::= { etherStatsHighCapacityEntry 14 }

etherStatsHighCapacityOverflowPkts1024to1518Octets OBJECT-TYPE

SYNTAX Counter32

UNITS "Packets"

MAX-ACCESS read-only

```

STATUS      current
DESCRIPTION
    "The number of times the associated
    etherStatsPkts1024to1518Octets counter has overflowed."
::= { etherStatsHighCapacityEntry 15 }

```

```

etherStatsHighCapacityPkts1024to1518Octets OBJECT-TYPE
    SYNTAX      Counter64
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The total number of packets (including bad
        packets) received that were between
        1024 and 1518 octets in length inclusive
        (excluding framing bits but including FCS octets)."
```

```

::= { etherStatsHighCapacityEntry 16 }

```

-- High Capacity extensions for the etherHistoryTable

```

etherHistoryHighCapacityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF EtherHistoryHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        etherHistoryTable."
```

```

::= { history 6 }

```

```

etherHistoryHighCapacityEntry OBJECT-TYPE
    SYNTAX      EtherHistoryHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        etherHistoryEntry. These objects will be created by the agent
        for all etherHistoryEntries associated with whichever
        historyControlEntries it deems appropriate. (i.e., either all
        etherHistoryHighCapacityEntries associated with a particular
        historyControlEntry will be created, or none of them will
        be.)"
```

```

INDEX { etherHistoryIndex, etherHistorySampleIndex }
::= { etherHistoryHighCapacityTable 1 }

```

```

EtherHistoryHighCapacityEntry ::= SEQUENCE {
    etherHistoryHighCapacityOverflowPkts      Gauge32,
    etherHistoryHighCapacityPkts              CounterBasedGauge64,
    etherHistoryHighCapacityOverflowOctets    Gauge32,

```

```
    etherHistoryHighCapacityOctets          CounterBasedGauge64
}
```

etherHistoryHighCapacityOverflowPkts OBJECT-TYPE

SYNTAX Gauge32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated etherHistoryPkts
Gauge overflowed during this sampling interval."

::= { etherHistoryHighCapacityEntry 1 }

etherHistoryHighCapacityPkts OBJECT-TYPE

SYNTAX CounterBasedGauge64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of packets (including bad packets,
broadcast packets, and multicast packets) received during
this sampling interval."

::= { etherHistoryHighCapacityEntry 2 }

etherHistoryHighCapacityOverflowOctets OBJECT-TYPE

SYNTAX Gauge32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated etherHistoryOctets
counter has overflowed during this sampling interval."

::= { etherHistoryHighCapacityEntry 3 }

etherHistoryHighCapacityOctets OBJECT-TYPE

SYNTAX CounterBasedGauge64

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of octets of data (including
those in bad packets) received on the
network (excluding framing bits but including
FCS octets) during this sampling interval."

::= { etherHistoryHighCapacityEntry 4 }

-- High Capacity Extensions for the hostTable


```

hostHighCapacityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF HostHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        hostTable."
    ::= { hosts 5 }

hostHighCapacityEntry OBJECT-TYPE
    SYNTAX      HostHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        hostEntry. These objects will be created by the agent
        for all hostEntries associated with whichever
        hostControlEntries it deems appropriate. (i.e., either all
        hostHighCapacityEntries associated with a particular
        hostControlEntry will be created, or none of them will
        be.)"
    INDEX { hostIndex, hostAddress }
    ::= { hostHighCapacityTable 1 }

HostHighCapacityEntry ::= SEQUENCE {
    hostHighCapacityInOverflowPkts    Counter32,
    hostHighCapacityInPkts            Counter64,
    hostHighCapacityOutOverflowPkts    Counter32,
    hostHighCapacityOutPkts            Counter64,
    hostHighCapacityInOverflowOctets    Counter32,
    hostHighCapacityInOctets            Counter64,
    hostHighCapacityOutOverflowOctets    Counter32,
    hostHighCapacityOutOctets            Counter64
}

hostHighCapacityInOverflowPkts OBJECT-TYPE
    SYNTAX      Counter32
    UNITS        "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of times the associated hostInPkts
        counter has overflowed."
    ::= { hostHighCapacityEntry 1 }

hostHighCapacityInPkts OBJECT-TYPE
    SYNTAX      Counter64
    UNITS        "Packets"

```

MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of good packets transmitted to
 this address since it was added to the
 hostHighCapacityTable."
 ::= { hostHighCapacityEntry 2 }

hostHighCapacityOutOverflowPkts OBJECT-TYPE
SYNTAX Counter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of times the associated hostOutPkts
 counter has overflowed."
 ::= { hostHighCapacityEntry 3 }

hostHighCapacityOutPkts OBJECT-TYPE
SYNTAX Counter64
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of packets, including bad packets, transmitted
 by this address since it was added to the
 hostHighCapacityTable."
 ::= { hostHighCapacityEntry 4 }

hostHighCapacityInOverflowOctets OBJECT-TYPE
SYNTAX Counter32
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of times the associated hostInOctets
 counter has overflowed."
 ::= { hostHighCapacityEntry 5 }

hostHighCapacityInOctets OBJECT-TYPE
SYNTAX Counter64
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of octets transmitted to this address
 since it was added to the hostHighCapacityTable (excluding
 framing bits but including FCS octets), except for

```
        those octets in bad packets."
 ::= { hostHighCapacityEntry 6 }
```

```
hostHighCapacityOutOverflowOctets OBJECT-TYPE
    SYNTAX      Counter32
    UNITS       "Octets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of times the associated hostOutOctets
        counter has overflowed."
 ::= { hostHighCapacityEntry 7 }
```

```
hostHighCapacityOutOctets OBJECT-TYPE
    SYNTAX      Counter64
    UNITS       "Octets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of octets transmitted by this address
        since it was added to the hostHighCapacityTable (excluding
        framing bits but including FCS octets), including
        those octets in bad packets."
 ::= { hostHighCapacityEntry 8 }
```

-- High Capacity extensions for the hostTimeTable

```
hostTimeHighCapacityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF HostTimeHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        hostTimeTable."
 ::= { hosts 6 }
```

```
hostTimeHighCapacityEntry OBJECT-TYPE
    SYNTAX      HostTimeHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        hostTimeEntry. These objects will be created by the agent
        for all hostTimeEntries associated with whichever
        hostControlEntries it deems appropriate. (i.e., either all
        hostTimeHighCapacityEntries associated with a particular
        hostControlEntry will be created, or none of them will
        be.)"
```

```

INDEX { hostTimeIndex, hostTimeCreationOrder }
 ::= { hostTimeHighCapacityTable 1 }

```

```

HostTimeHighCapacityEntry ::= SEQUENCE {
    hostTimeHighCapacityInOverflowPkts    Counter32,
    hostTimeHighCapacityInPkts           Counter64,
    hostTimeHighCapacityOutOverflowPkts   Counter32,
    hostTimeHighCapacityOutPkts           Counter64,
    hostTimeHighCapacityInOverflowOctets  Counter32,
    hostTimeHighCapacityInOctets          Counter64,
    hostTimeHighCapacityOutOverflowOctets Counter32,
    hostTimeHighCapacityOutOctets         Counter64
}

```

```

hostTimeHighCapacityInOverflowPkts OBJECT-TYPE
    SYNTAX      Counter32
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of times the associated hostTimeInPkts
        counter has overflowed."
    ::= { hostTimeHighCapacityEntry 1 }

```

```

hostTimeHighCapacityInPkts OBJECT-TYPE
    SYNTAX      Counter64
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of good packets transmitted to this address
        since it was added to the hostTimeHighCapacityTable."
    ::= { hostTimeHighCapacityEntry 2 }

```

```

hostTimeHighCapacityOutOverflowPkts OBJECT-TYPE
    SYNTAX      Counter32
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of times the associated hostTimeOutPkts
        counter has overflowed."
    ::= { hostTimeHighCapacityEntry 3 }

```

```

hostTimeHighCapacityOutPkts OBJECT-TYPE
    SYNTAX      Counter64
    UNITS       "Packets"
    MAX-ACCESS  read-only

```

STATUS current
DESCRIPTION
"The number of packets, including bad packets, transmitted
by this address since it was added to the
hostTimeHighCapacityTable."
::= { hostTimeHighCapacityEntry 4 }

hostTimeHighCapacityInOverflowOctets OBJECT-TYPE
SYNTAX Counter32
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of times the associated hostTimeInOctets
counter has overflowed."
::= { hostTimeHighCapacityEntry 5 }

hostTimeHighCapacityInOctets OBJECT-TYPE
SYNTAX Counter64
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of octets transmitted to this address
since it was added to the hostTimeHighCapacityTable
(excluding framing bits but including FCS octets),
except for those octets in bad packets."
::= { hostTimeHighCapacityEntry 6 }

hostTimeHighCapacityOutOverflowOctets OBJECT-TYPE
SYNTAX Counter32
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of times the associated hostTimeOutOctets
counter has overflowed."
::= { hostTimeHighCapacityEntry 7 }

hostTimeHighCapacityOutOctets OBJECT-TYPE
SYNTAX Counter64
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of octets transmitted by this address since
it was added to the hostTimeTable (excluding framing
bits but including FCS octets), including those

```

        octets in bad packets."
    ::= { hostTimeHighCapacityEntry 8 }

-- High Capacity Extensions for the hostTopNTable

hostTopNHighCapacityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF HostTopNHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        hostTopNTable when hostTopNRateBase specifies a High Capacity
        TopN Report."
    ::= { hostTopN 3 }

hostTopNHighCapacityEntry OBJECT-TYPE
    SYNTAX      HostTopNHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        hostTopNEntry when hostTopNRateBase specifies a High Capacity
        TopN Report. These objects will be created by the agent
        for all hostTopNEntries associated with whichever
        hostTopNControlEntries have a hostTopNRateBase that specify
        a high capacity report."
    INDEX { hostTopNReport, hostTopNIndex }
    ::= { hostTopNHighCapacityTable 1 }

HostTopNHighCapacityEntry ::= SEQUENCE {
    hostTopNHighCapacityAddress      OCTET STRING,
    hostTopNHighCapacityBaseRate     Gauge32,
    hostTopNHighCapacityOverflowRate Gauge32,
    hostTopNHighCapacityRate         CounterBasedGauge64
}

hostTopNHighCapacityAddress OBJECT-TYPE
    SYNTAX      OCTET STRING
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The physical address of this host."
    ::= { hostTopNHighCapacityEntry 1 }

hostTopNHighCapacityBaseRate OBJECT-TYPE
    SYNTAX      Gauge32
    MAX-ACCESS  read-only
    STATUS      current

```

DESCRIPTION

"The amount of change in the selected variable during this sampling interval, modulo 2^{32} . The selected variable is this host's instance of the object selected by hostTopNRateBase."

::= { hostTopNHighCapacityEntry 2 }

hostTopNHighCapacityOverflowRate OBJECT-TYPE

SYNTAX Gauge32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The amount of change in the selected variable during this sampling interval, divided by 2^{32} , truncating fractions (i.e., $X \text{ DIV } 2^{32}$). The selected variable is this host's instance of the object selected by hostTopNRateBase."

::= { hostTopNHighCapacityEntry 3 }

hostTopNHighCapacityRate OBJECT-TYPE

SYNTAX CounterBasedGauge64

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The amount of change in the selected variable during this sampling interval. The selected variable is this host's instance of the object selected by hostTopNRateBase."

::= { hostTopNHighCapacityEntry 4 }

-- High Capacity Extensions for the matrixSDTable

matrixSDHighCapacityTable OBJECT-TYPE

SYNTAX SEQUENCE OF MatrixSDHighCapacityEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Contains the High Capacity RMON extensions to the RMON-1 matrixSDTable."

::= { matrix 5 }

matrixSDHighCapacityEntry OBJECT-TYPE

SYNTAX MatrixSDHighCapacityEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Contains the High Capacity RMON extensions to the RMON-1 matrixSDEntry. These objects will be created by the agent"

```

        for all matrixSDEntries associated with whichever
        matrixControlEntries it deems appropriate. (i.e., either all
        matrixSDHighCapacityEntries associated with a particular
        matrixControlEntry will be created, or none of them will
        be.)"
INDEX { matrixSDIndex,
        matrixSDSourceAddress, matrixSDDestAddress }
 ::= { matrixSDHighCapacityTable 1 }

MatrixSDHighCapacityEntry ::= SEQUENCE {
    matrixSDHighCapacityOverflowPkts Counter32,
    matrixSDHighCapacityPkts         Counter64,
    matrixSDHighCapacityOverflowOctets Counter32,
    matrixSDHighCapacityOctets        Counter64
}

matrixSDHighCapacityOverflowPkts OBJECT-TYPE
    SYNTAX      Counter32
    UNITS        "Packets"
    MAX-ACCESS  read-only
    STATUS       current
    DESCRIPTION
        "The number of times the associated matrixSDPkts
        counter has overflowed."
    ::= { matrixSDHighCapacityEntry 1 }

matrixSDHighCapacityPkts OBJECT-TYPE
    SYNTAX      Counter64
    UNITS        "Packets"
    MAX-ACCESS  read-only
    STATUS       current
    DESCRIPTION
        "The number of packets transmitted from the source
        address to the destination address (this number
        includes bad packets)."
    ::= { matrixSDHighCapacityEntry 2 }

matrixSDHighCapacityOverflowOctets OBJECT-TYPE
    SYNTAX      Counter32
    UNITS        "Octets"
    MAX-ACCESS  read-only
    STATUS       current
    DESCRIPTION
        "The number of times the associated matrixSDOctets
        counter has overflowed."
    ::= { matrixSDHighCapacityEntry 3 }

matrixSDHighCapacityOctets OBJECT-TYPE

```



```

SYNTAX      Counter64
UNITS       "Octets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
    "The number of octets (excluding framing bits but
    including FCS octets) contained in all packets
    transmitted from the source address to the
    destination address."
 ::= { matrixSDHighCapacityEntry 4 }

```

-- High Capacity extensions for the matrixDSTable

```

matrixDSHighCapacityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF MatrixDSHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        matrixDSTable."
    ::= { matrix 6 }

```

```

matrixDSHighCapacityEntry OBJECT-TYPE
    SYNTAX      MatrixDSHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        matrixDSEntry. These objects will be created by the agent
        for all matrixDSEntries associated with whichever
        matrixControlEntries it deems appropriate. (i.e., either all
        matrixDSHighCapacityEntries associated with a particular
        matrixControlEntry will be created, or none of them will
        be.)"
    INDEX { matrixDSIndex,
            matrixDSDestAddress, matrixDSSourceAddress }
    ::= { matrixDSHighCapacityTable 1 }

```

```

MatrixDSHighCapacityEntry ::= SEQUENCE {
    matrixDSHighCapacityOverflowPkts Counter32,
    matrixDSHighCapacityPkts         Counter64,
    matrixDSHighCapacityOverflowOctets Counter32,
    matrixDSHighCapacityOctets        Counter64
}

```

```

matrixDSHighCapacityOverflowPkts OBJECT-TYPE
    SYNTAX      Counter32
    UNITS       "Packets"

```

MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of times the associated matrixDSPkts
 counter has overflowed."
::= { matrixDSHighCapacityEntry 1 }

matrixDSHighCapacityPkts OBJECT-TYPE
SYNTAX Counter64
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of packets transmitted from the source
 address to the destination address (this number
 includes bad packets)."
::= { matrixDSHighCapacityEntry 2 }

matrixDSHighCapacityOverflowOctets OBJECT-TYPE
SYNTAX Counter32
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of times the associated matrixDSOctets
 counter has overflowed."
::= { matrixDSHighCapacityEntry 3 }

matrixDSHighCapacityOctets OBJECT-TYPE
SYNTAX Counter64
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of octets (excluding framing bits
 but including FCS octets) contained in all packets
 transmitted from the source address to the
 destination address."
::= { matrixDSHighCapacityEntry 4 }

-- High Capacity extensions for the captureBufferTable

captureBufferHighCapacityTable OBJECT-TYPE
SYNTAX SEQUENCE OF CaptureBufferHighCapacityEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
 "Contains the High Capacity RMON extensions to the RMON-1

```

        captureBufferTable."
 ::= { capture 3 }

captureBufferHighCapacityEntry OBJECT-TYPE
    SYNTAX      CaptureBufferHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-1
        captureBufferEntry. These objects will be created by the agent
        for all captureBufferEntries associated with whichever
        bufferControlEntries it deems appropriate. (i.e., either all
        captureBufferHighCapacityEntries associated with a particular
        bufferControlEntry will be created, or none of them will
        be.)"
    INDEX { captureBufferControlIndex, captureBufferIndex }
    ::= { captureBufferHighCapacityTable 1 }

CaptureBufferHighCapacityEntry ::= SEQUENCE {
    captureBufferPacketHighCapacityTime      Integer32
}

captureBufferPacketHighCapacityTime OBJECT-TYPE
    SYNTAX      Integer32 (0..999999)
    UNITS       "nanoseconds"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of nanoseconds that had passed since this capture
        buffer was first turned on when this packet was captured,
        modulo 10^6.

        This object is used in conjunction with the
        captureBufferPacketTime object. This object returns the
        number of nano-seconds to be added to to number of
        milli-seconds obtained from the captureBufferPacketTime
        object, to obtain more accurate inter packet arrival time."
    ::= { captureBufferHighCapacityEntry 1 }

-- High Capacity extensions for the protocolDistStatsTable

protocolDistStatsHighCapacityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF ProtocolDistStatsHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        protocolDistStatsTable."

```

```
::= { protocolDist 3 }
```

```
protocolDistStatsHighCapacityEntry OBJECT-TYPE
```

```
SYNTAX      ProtocolDistStatsHighCapacityEntry
```

```
MAX-ACCESS  not-accessible
```

```
STATUS      current
```

```
DESCRIPTION
```

"Contains the High Capacity RMON extensions to the RMON-2 protocolDistStatsTable. These objects will be created by the agent for all protocolDistStatsEntries associated with whichever protocolDistControlEntries it deems appropriate. (i.e., either all protocolDistStatsHighCapacityEntries associated with a particular protocolDistControlEntry will be created, or none of them will be.)"

```
INDEX { protocolDistControlIndex, protocolDirLocalIndex }
```

```
::= { protocolDistStatsHighCapacityTable 1 }
```

```
ProtocolDistStatsHighCapacityEntry ::= SEQUENCE {
```

```
    protocolDistStatsHighCapacityOverflowPkts  ZeroBasedCounter32,
```

```
    protocolDistStatsHighCapacityPkts          ZeroBasedCounter64,
```

```
    protocolDistStatsHighCapacityOverflowOctets ZeroBasedCounter32,
```

```
    protocolDistStatsHighCapacityOctets        ZeroBasedCounter64
```

```
}
```

```
protocolDistStatsHighCapacityOverflowPkts OBJECT-TYPE
```

```
SYNTAX      ZeroBasedCounter32
```

```
UNITS       "Packets"
```

```
MAX-ACCESS  read-only
```

```
STATUS      current
```

```
DESCRIPTION
```

"The number of times the associated protocolDistStatsPkts counter has overflowed."

```
::= { protocolDistStatsHighCapacityEntry 1 }
```

```
protocolDistStatsHighCapacityPkts OBJECT-TYPE
```

```
SYNTAX      ZeroBasedCounter64
```

```
UNITS       "Packets"
```

```
MAX-ACCESS  read-only
```

```
STATUS      current
```

```
DESCRIPTION
```

"The number of packets without errors received of this protocol type. Note that this is the number of link-layer packets, so if a single network-layer packet is fragmented into several link-layer frames, this counter is incremented several times."

```
::= { protocolDistStatsHighCapacityEntry 2 }
```

```
protocolDistStatsHighCapacityOverflowOctets OBJECT-TYPE
```

SYNTAX ZeroBasedCounter32
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of times the associated protocolDistStatsOctets
 counter has overflowed."
 ::= { protocolDistStatsHighCapacityEntry 3 }

protocolDistStatsHighCapacityOctets OBJECT-TYPE

SYNTAX ZeroBasedCounter64
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of octets in packets received of this protocol
 type since it was added to the protocolDistStatsTable
 (excluding framing bits but including FCS octets), except for
 those octets in packets that contained errors.

 Note this doesn't count just those octets in the particular
 protocol frames, but includes the entire packet that contained
 the protocol."
 ::= { protocolDistStatsHighCapacityEntry 4 }

-- High Capacity extensions for the nlHostTable.

nlHostHighCapacityTable OBJECT-TYPE

SYNTAX SEQUENCE OF NlHostHighCapacityEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
 "Contains the High Capacity RMON extensions to the RMON-2
 nlHostTable."
 ::= { nlHost 3 }

nlHostHighCapacityEntry OBJECT-TYPE

SYNTAX NlHostHighCapacityEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
 "Contains the High Capacity RMON extensions to the RMON-2
 nlHostEntry. These objects will be created by the agent
 for all nlHostEntries associated with whichever
 hlHostControlEntries it deems appropriate. (i.e., either all
 nlHostHighCapacityEntries associated with a particular
 hlHostControlEntry will be created, or none of them will
 be.)"

```

INDEX { hlHostControlIndex, nlHostTimeMark,
        protocolDirLocalIndex, nlHostAddress }
 ::= { nlHostHighCapacityTable 1 }

```

```

NlHostHighCapacityEntry ::= SEQUENCE {
    nlHostHighCapacityInOverflowPkts    ZeroBasedCounter32,
    nlHostHighCapacityInPkts           ZeroBasedCounter64,
    nlHostHighCapacityOutOverflowPkts   ZeroBasedCounter32,
    nlHostHighCapacityOutPkts          ZeroBasedCounter64,
    nlHostHighCapacityInOverflowOctets  ZeroBasedCounter32,
    nlHostHighCapacityInOctets         ZeroBasedCounter64,
    nlHostHighCapacityOutOverflowOctets ZeroBasedCounter32,
    nlHostHighCapacityOutOctets        ZeroBasedCounter64
}

```

```

nlHostHighCapacityInOverflowPkts OBJECT-TYPE
    SYNTAX      ZeroBasedCounter32
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of times the associated nlHostInPkts
        counter has overflowed."
    ::= { nlHostHighCapacityEntry 1 }

```

```

nlHostHighCapacityInPkts OBJECT-TYPE
    SYNTAX      ZeroBasedCounter64
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of packets without errors transmitted to
        this address since it was added to the nlHostHighCapacityTable.
        Note that this is the number of link-layer packets, so if a
        single network-layer packet is fragmented into several
        link-layer frames, this counter is incremented several times."
    ::= { nlHostHighCapacityEntry 2 }

```

```

nlHostHighCapacityOutOverflowPkts OBJECT-TYPE
    SYNTAX      ZeroBasedCounter32
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of times the associated nlHostOutPkts
        counter has overflowed."
    ::= { nlHostHighCapacityEntry 3 }

```

nlHostHighCapacityOutPkts OBJECT-TYPE

SYNTAX ZeroBasedCounter64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of packets without errors transmitted by this address since it was added to the nlHostHighCapacityTable. Note that this is the number of link-layer packets, so if a single network-layer packet is fragmented into several link-layer frames, this counter is incremented several times."

::= { nlHostHighCapacityEntry 4 }

nlHostHighCapacityInOverflowOctets OBJECT-TYPE

SYNTAX ZeroBasedCounter32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated nlHostInOctets counter has overflowed."

::= { nlHostHighCapacityEntry 5 }

nlHostHighCapacityInOctets OBJECT-TYPE

SYNTAX ZeroBasedCounter64

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets transmitted to this address since it was added to the nlHostHighCapacityTable (excluding framing bits but including FCS octets), excluding those octets in packets that contained errors."

Note this doesn't count just those octets in the particular protocol frames, but includes the entire packet that contained the protocol."

::= { nlHostHighCapacityEntry 6 }

nlHostHighCapacityOutOverflowOctets OBJECT-TYPE

SYNTAX ZeroBasedCounter32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated nlHostOutOctets counter has overflowed."

```
::= { nlHostHighCapacityEntry 7 }
```

```
nlHostHighCapacityOutOctets OBJECT-TYPE
```

```
SYNTAX      ZeroBasedCounter64
```

```
UNITS       "Octets"
```

```
MAX-ACCESS  read-only
```

```
STATUS      current
```

```
DESCRIPTION
```

"The number of octets transmitted by this address since it was added to the nlHostHighCapacityTable (excluding framing bits but including FCS octets), excluding those octets in packets that contained errors.

Note this doesn't count just those octets in the particular protocol frames, but includes the entire packet that contained the protocol."

```
::= { nlHostHighCapacityEntry 8 }
```

```
-- High Capacity extensions for the nlMatrixTable
```

```
nlMatrixSDHighCapacityTable OBJECT-TYPE
```

```
SYNTAX      SEQUENCE OF NlMatrixSDHighCapacityEntry
```

```
MAX-ACCESS  not-accessible
```

```
STATUS      current
```

```
DESCRIPTION
```

"Contains the High Capacity RMON extensions to the RMON-2 nlMatrixTable."

```
::= { nlMatrix 6 }
```

```
nlMatrixSDHighCapacityEntry OBJECT-TYPE
```

```
SYNTAX      NlMatrixSDHighCapacityEntry
```

```
MAX-ACCESS  not-accessible
```

```
STATUS      current
```

```
DESCRIPTION
```

"Contains the High Capacity RMON extensions to the RMON-2 nlMatrixEntry. These objects will be created by the agent for all nlMatrixSDEntries associated with whichever hlMatrixControlEntries it deems appropriate. (i.e., either all nlMatrixSDHighCapacityEntries associated with a particular hlMatrixControlEntry will be created, or none of them will be.)"

```
INDEX { hlMatrixControlIndex, nlMatrixSDTimeMark,
        protocolDirLocalIndex,
        nlMatrixSDSourceAddress, nlMatrixSDDestAddress }
```

```
::= { nlMatrixSDHighCapacityTable 1 }
```

```
NlMatrixSDHighCapacityEntry ::= SEQUENCE {
```



```
nlMatrixSDHighCapacityOverflowPkts    ZeroBasedCounter32,
nlMatrixSDHighCapacityPkts            ZeroBasedCounter64,
nlMatrixSDHighCapacityOverflowOctets  ZeroBasedCounter32,
nlMatrixSDHighCapacityOctets          ZeroBasedCounter64
}
```

nlMatrixSDHighCapacityOverflowPkts OBJECT-TYPE
SYNTAX ZeroBasedCounter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of times the associated nlMatrixSDPkts
counter has overflowed."
::= { nlMatrixSDHighCapacityEntry 1 }

nlMatrixSDHighCapacityPkts OBJECT-TYPE
SYNTAX ZeroBasedCounter64
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of packets without errors transmitted from the
source address to the destination address since this entry was
added to the nlMatrixSDHighCapacityTable. Note that this is
the number of link-layer packets, so if a single network-layer
packet is fragmented into several link-layer frames, this
counter is incremented several times."
::= { nlMatrixSDHighCapacityEntry 2 }

nlMatrixSDHighCapacityOverflowOctets OBJECT-TYPE
SYNTAX ZeroBasedCounter32
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of times the associated nlMatrixSDOctets
counter has overflowed."
::= { nlMatrixSDHighCapacityEntry 3 }

nlMatrixSDHighCapacityOctets OBJECT-TYPE
SYNTAX ZeroBasedCounter64
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of octets transmitted from the source address to
the destination address since this entry was added to the

nlMatrixSDHighCapacityTable (excluding framing bits but including FCS octets), excluding those octets in packets that contained errors.

Note this doesn't count just those octets in the particular protocol frames, but includes the entire packet that contained the protocol."

```
::= { nlMatrixSDHighCapacityEntry 4 }
```

-- High Capacity extensions for the nlMatrixDSTable

```
nlMatrixDSHighCapacityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF NlMatrixDSHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        nlMatrixDSTable."
    ::= { nlMatrix 7 }
```

```
nlMatrixDSHighCapacityEntry OBJECT-TYPE
    SYNTAX      NlMatrixDSHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        nlMatrixDSEntry. These objects will be created by the agent
        for all nlMatrixDSEntries associated with whichever
        hlMatrixControlEntries it deems appropriate. (i.e., either all
        nlMatrixDSHighCapacityEntries associated with a particular
        hlMatrixControlEntry will be created, or none of them will
        be.)"
    INDEX { hlMatrixControlIndex, nlMatrixDSTimeMark,
            protocolDirLocalIndex,
            nlMatrixDSDestAddress, nlMatrixDSSourceAddress }
    ::= { nlMatrixDSHighCapacityTable 1 }
```

```
NlMatrixDSHighCapacityEntry ::= SEQUENCE {
    nlMatrixDSHighCapacityOverflowPkts  ZeroBasedCounter32,
    nlMatrixDSHighCapacityPkts          ZeroBasedCounter64,
    nlMatrixDSHighCapacityOverflowOctets ZeroBasedCounter32,
    nlMatrixDSHighCapacityOctets         ZeroBasedCounter64
}
```

```
nlMatrixDSHighCapacityOverflowPkts OBJECT-TYPE
    SYNTAX      ZeroBasedCounter32
    UNITS       "Packets"
    MAX-ACCESS  read-only
```

```

STATUS      current
DESCRIPTION
    "The number of times the associated nlMatrixDSPkts
    counter has overflowed."
::= { nlMatrixDSHighCapacityEntry 1 }

```

```

nlMatrixDSHighCapacityPkts OBJECT-TYPE
    SYNTAX      ZeroBasedCounter64
    UNITS        "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of packets without errors transmitted from the
        source address to the destination address since this entry was
        added to the nlMatrixDSHighCapacityTable. Note that this is
        the number of link-layer packets, so if a single network-layer
        packet is fragmented into several link-layer frames, this
        counter is incremented several times."
    ::= { nlMatrixDSHighCapacityEntry 2 }

```

```

nlMatrixDSHighCapacityOverflowOctets OBJECT-TYPE
    SYNTAX      ZeroBasedCounter32
    UNITS        "Octets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of times the associated nlMatrixDSOctets
        counter has overflowed."
    ::= { nlMatrixDSHighCapacityEntry 3 }

```

```

nlMatrixDSHighCapacityOctets OBJECT-TYPE
    SYNTAX      ZeroBasedCounter64
    UNITS        "Octets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of octets transmitted from the source address
        to the destination address since this entry was added to the
        nlMatrixDSHighCapacityTable (excluding framing bits but
        including FCS octets), excluding those octets in packets that
        contained errors.

        Note this doesn't count just those octets in the particular
        protocol frames, but includes the entire packet that contained
        the protocol."
    ::= { nlMatrixDSHighCapacityEntry 4 }

```

```
-- High Capacity extensions for the nlMatrixTopNTable
```

nlMatrixTopNHighCapacityTable OBJECT-TYPE

SYNTAX SEQUENCE OF NlMatrixTopNHighCapacityEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Contains the High Capacity RMON extensions to the RMON-2
nlMatrixTopNTable when nlMatrixTopNControlRateBase specifies
a High Capacity TopN Report."

::= { nlMatrix 8 }

nlMatrixTopNHighCapacityEntry OBJECT-TYPE

SYNTAX NlMatrixTopNHighCapacityEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Contains the High Capacity RMON extensions to the RMON-2
nlMatrixTopNEntry when nlMatrixTopNControlRateBase specifies
a High Capacity TopN Report. These objects will be created by
the agent for all nlMatrixTopNEntries associated with whichever
nlMatrixTopNControlEntries have a nlMatrixTopNControlRateBase
that specify a high capacity report."

INDEX { nlMatrixTopNControlIndex, nlMatrixTopNIndex }

::= { nlMatrixTopNHighCapacityTable 1 }

NlMatrixTopNHighCapacityEntry ::= SEQUENCE {

nlMatrixTopNHighCapacityProtocolDirLocalIndex	Integer32,
nlMatrixTopNHighCapacitySourceAddress	OCTET STRING,
nlMatrixTopNHighCapacityDestAddress	OCTET STRING,
nlMatrixTopNHighCapacityBasePktRate	Gauge32,
nlMatrixTopNHighCapacityOverflowPktRate	Gauge32,
nlMatrixTopNHighCapacityPktRate	CounterBasedGauge64,
nlMatrixTopNHighCapacityReverseBasePktRate	Gauge32,
nlMatrixTopNHighCapacityReverseOverflowPktRate	Gauge32,
nlMatrixTopNHighCapacityReversePktRate	CounterBasedGauge64,
nlMatrixTopNHighCapacityBaseOctetRate	Gauge32,
nlMatrixTopNHighCapacityOverflowOctetRate	Gauge32,
nlMatrixTopNHighCapacityOctetRate	CounterBasedGauge64,
nlMatrixTopNHighCapacityReverseBaseOctetRate	Gauge32,
nlMatrixTopNHighCapacityReverseOverflowOctetRate	Gauge32,
nlMatrixTopNHighCapacityReverseOctetRate	CounterBasedGauge64

}

nlMatrixTopNHighCapacityProtocolDirLocalIndex OBJECT-TYPE

SYNTAX Integer32 (1..2147483647)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The protocolDirLocalIndex of the network layer protocol of

this entry's network address."
 ::= { nlMatrixTopNHighCapacityEntry 1 }

nlMatrixTopNHighCapacitySourceAddress OBJECT-TYPE

SYNTAX OCTET STRING

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The network layer address of the source host in this conversation.

This is represented as an octet string with specific semantics and length as identified by the associated nlMatrixTopNProtocolDirLocalIndex.

For example, if the protocolDirLocalIndex indicates an encapsulation of ip, this object is encoded as a length octet of 4, followed by the 4 octets of the ip address, in network byte order."

::= { nlMatrixTopNHighCapacityEntry 2 }

nlMatrixTopNHighCapacityDestAddress OBJECT-TYPE

SYNTAX OCTET STRING

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The network layer address of the destination host in this conversation.

This is represented as an octet string with specific semantics and length as identified by the associated nlMatrixTopNProtocolDirLocalIndex.

For example, if the nlMatrixTopNProtocolDirLocalIndex indicates an encapsulation of ip, this object is encoded as a length octet of 4, followed by the 4 octets of the ip address, in network byte order."

::= { nlMatrixTopNHighCapacityEntry 3 }

nlMatrixTopNHighCapacityBasePktRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of packets seen from the source host to the destination host during this sampling interval, modulo 2^32, counted using the rules for counting the

```
nlMatrixSDPkts object."  
::= { nlMatrixTopNHighCapacityEntry 4 }
```

nlMatrixTopNHighCapacityOverflowPktRate OBJECT-TYPE

```
SYNTAX      Gauge32  
UNITS       "Packets"  
MAX-ACCESS  read-only  
STATUS      current  
DESCRIPTION  
    "The number of packets seen from the source host  
    to the destination host during this sampling interval,  
    divided by 2^32, truncating fractions (i.e., X DIV 2^32),  
    and counted using the rules for counting the  
    nlMatrixSDPkts object."  
::= { nlMatrixTopNHighCapacityEntry 5 }
```

nlMatrixTopNHighCapacityPktRate OBJECT-TYPE

```
SYNTAX      CounterBasedGauge64  
UNITS       "Packets"  
MAX-ACCESS  read-only  
STATUS      current  
DESCRIPTION  
    "The number of packets seen from the source host to the  
    destination host during this sampling interval, counted  
    using the rules for counting the nlMatrixSDPkts object.  
    If the value of nlMatrixTopNControlRateBase is  
    nlMatrixTopNHighCapacityPkts, this variable will be  
    used to sort this report."  
::= { nlMatrixTopNHighCapacityEntry 6 }
```

nlMatrixTopNHighCapacityReverseBasePktRate OBJECT-TYPE

```
SYNTAX      Gauge32  
UNITS       "Packets"  
MAX-ACCESS  read-only  
STATUS      current  
DESCRIPTION  
    "The number of packets seen from the destination host to the  
    source host during this sampling interval, modulo 2^32, counted  
    using the rules for counting the nlMatrixSDPkts object (note  
    that the corresponding nlMatrixSDPkts object selected is the  
    one whose source address is equal to nlMatrixTopNDestAddress  
    and whose destination address is equal to  
    nlMatrixTopNSourceAddress.)"
```

Note that if the value of nlMatrixTopNControlRateBase is equal to nlMatrixTopNHighCapacityPkts, the sort of topN entries is based entirely on nlMatrixTopNHighCapacityPktRate, and not on the value of this object."

```
::= { nlMatrixTopNHighCapacityEntry 7 }
```

nlMatrixTopNHighCapacityReverseOverflowPktRate OBJECT-TYPE

```
SYNTAX      Gauge32
UNITS       "Packets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
```

"The number of packets seen from the destination host to the source host during this sampling interval, divided by 2^{32} , truncating fractions (i.e., $X \text{ DIV } 2^{32}$), and counted using the rules for counting the nlMatrixSDPkts object (note that the corresponding nlMatrixSDPkts object selected is the one whose source address is equal to nlMatrixTopNDestAddress and whose destination address is equal to nlMatrixTopNSourceAddress.)"

Note that if the value of nlMatrixTopNControlRateBase is equal to nlMatrixTopNHighCapacityPkts, the sort of topN entries is based entirely on nlMatrixTopNHighCapacityPktRate, and not on the value of this object."

```
::= { nlMatrixTopNHighCapacityEntry 8 }
```

nlMatrixTopNHighCapacityReversePktRate OBJECT-TYPE

```
SYNTAX      CounterBasedGauge64
UNITS       "Packets"
MAX-ACCESS  read-only
STATUS      current
DESCRIPTION
```

"The number of packets seen from the destination host to the source host during this sampling interval, counted using the rules for counting the nlMatrixSDPkts object (note that the corresponding nlMatrixSDPkts object selected is the one whose source address is equal to nlMatrixTopNDestAddress and whose destination address is equal to nlMatrixTopNSourceAddress.)"

Note that if the value of nlMatrixTopNControlRateBase is equal to nlMatrixTopNHighCapacityPkts, the sort of topN entries is based entirely on nlMatrixTopNHighCapacityPktRate, and not on the value of this object."

```
::= { nlMatrixTopNHighCapacityEntry 9 }
```

nlMatrixTopNHighCapacityBaseOctetRate OBJECT-TYPE

```
SYNTAX      Gauge32
UNITS       "Octets"
MAX-ACCESS  read-only
STATUS      current
```

DESCRIPTION

"The number of octets seen from the source host to the destination host during this sampling interval, modulo 2^{32} , counted using the rules for counting the nlMatrixSDOctets object."

::= { nlMatrixTopNHighCapacityEntry 10 }

nlMatrixTopNHighCapacityOverflowOctetRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen from the source host to the destination host during this sampling interval, divided by 2^{32} , truncating fractions (i.e., $X \text{ DIV } 2^{32}$), and counted using the rules for counting the nlMatrixSDOctets object."

::= { nlMatrixTopNHighCapacityEntry 11 }

nlMatrixTopNHighCapacityOctetRate OBJECT-TYPE

SYNTAX CounterBasedGauge64

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen from the source host to the destination host during this sampling interval, counted using the rules for counting the nlMatrixSDOctets object.

If the value of nlMatrixTopNControlRateBase is nlMatrixTopNHighCapacityOctets, this variable will be used to sort this report."

::= { nlMatrixTopNHighCapacityEntry 12 }

nlMatrixTopNHighCapacityReverseBaseOctetRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen from the destination host to the source host during this sampling interval, modulo 2^{32} , counted using the rules for counting the nlMatrixSDOctets object (note that the corresponding nlMatrixSDOctets object selected is the one whose source address is equal to nlMatrixTopNDestAddress and whose destination address is equal to nlMatrixTopNSourceAddress.)"

Note that if the value of nlMatrixTopNControlRateBase is equal to nlMatrixTopNHighCapacityOctets, the sort of topN entries is based entirely on nlMatrixTopNHighCapacityOctetRate, and not on the value of this object."

```
::= { nlMatrixTopNHighCapacityEntry 13 }
```

nlMatrixTopNHighCapacityReverseOverflowOctetRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen from the destination host to the source host during this sampling interval, divided by 2^32, truncating fractions (i.e., X DIV 2^32), and counted using the rules for counting the nlMatrixSDOctets object (note that the corresponding nlMatrixSDOctets object selected is the one whose source address is equal to nlMatrixTopNDestAddress and whose destination address is equal to nlMatrixTopNSourceAddress.)"

Note that if the value of nlMatrixTopNControlRateBase is equal to nlMatrixTopNHighCapacityOctets, the sort of topN entries is based entirely on nlMatrixTopNHighCapacityOctetRate, and not on the value of this object."

```
::= { nlMatrixTopNHighCapacityEntry 14 }
```

nlMatrixTopNHighCapacityReverseOctetRate OBJECT-TYPE

SYNTAX CounterBasedGauge64

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen from the destination host to the source host during this sampling interval, counted using the rules for counting the nlMatrixSDOctets object (note that the corresponding nlMatrixSDOctets object selected is the one whose source address is equal to nlMatrixTopNDestAddress and whose destination address is equal to nlMatrixTopNSourceAddress.)"

Note that if the value of nlMatrixTopNControlRateBase is equal to nlMatrixTopNHighCapacityOctets, the sort of topN entries is based entirely on nlMatrixTopNHighCapacityOctetRate, and not on the value of this object."

```
::= { nlMatrixTopNHighCapacityEntry 15 }
```

```
-- High Capacity extensions for the alHostTable
```

```

alHostHighCapacityTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF AlHostHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        alHostTable."
    ::= { alHost 2 }

alHostHighCapacityEntry OBJECT-TYPE
    SYNTAX      AlHostHighCapacityEntry
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "Contains the High Capacity RMON extensions to the RMON-2
        alHostEntry. These objects will be created by the agent
        for all alHostEntries associated with whichever
        hlHostControlEntries it deems appropriate. (i.e., either all
        alHostHighCapacityEntries associated with a particular
        hlHostControlEntry will be created, or none of them will
        be.)"
    INDEX { hlHostControlIndex, alHostTimeMark,
            protocolDirLocalIndex, nlHostAddress,
            protocolDirLocalIndex }
    ::= { alHostHighCapacityTable 1 }

AlHostHighCapacityEntry ::= SEQUENCE {
    alHostHighCapacityInOverflowPkts    ZeroBasedCounter32,
    alHostHighCapacityInPkts           ZeroBasedCounter64,
    alHostHighCapacityOutOverflowPkts   ZeroBasedCounter32,
    alHostHighCapacityOutPkts          ZeroBasedCounter64,
    alHostHighCapacityInOverflowOctets  ZeroBasedCounter32,
    alHostHighCapacityInOctets         ZeroBasedCounter64,
    alHostHighCapacityOutOverflowOctets ZeroBasedCounter32,
    alHostHighCapacityOutOctets        ZeroBasedCounter64
}

alHostHighCapacityInOverflowPkts OBJECT-TYPE
    SYNTAX      ZeroBasedCounter32
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of times the associated alHostInPkts
        counter has overflowed."

    ::= { alHostHighCapacityEntry 1 }

```

alHostHighCapacityInPkts OBJECT-TYPE
SYNTAX ZeroBasedCounter64
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of packets of this protocol type without errors
 transmitted to this address since it was added to the
 alHostHighCapacityTable. Note that this is the number of
 link-layer packets, so if a single network-layer packet
 is fragmented into several link-layer frames, this counter
 is incremented several times."
 ::= { alHostHighCapacityEntry 2 }

alHostHighCapacityOutOverflowPkts OBJECT-TYPE
SYNTAX ZeroBasedCounter32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of times the associated alHostOutPkts
 counter has overflowed."
 ::= { alHostHighCapacityEntry 3 }

alHostHighCapacityOutPkts OBJECT-TYPE
SYNTAX ZeroBasedCounter64
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of packets of this protocol type without errors
 transmitted by this address since it was added to the
 alHostHighCapacityTable. Note that this is the number of
 link-layer packets, so if a single network-layer packet
 is fragmented into several link-layer frames, this counter
 is incremented several times."
 ::= { alHostHighCapacityEntry 4 }

alHostHighCapacityInOverflowOctets OBJECT-TYPE
SYNTAX ZeroBasedCounter32
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
 "The number of times the associated alHostInOctets
 counter has overflowed."
 ::= { alHostHighCapacityEntry 5 }

`alHostHighCapacityInOctets OBJECT-TYPE``SYNTAX ZeroBasedCounter64``UNITS "Octets"``MAX-ACCESS read-only``STATUS current``DESCRIPTION`

"The number of octets transmitted to this address of this protocol type since it was added to the `alHostHighCapacityTable` (excluding framing bits but including FCS octets), excluding those octets in packets that contained errors.

Note this doesn't count just those octets in the particular protocol frames, but includes the entire packet that contained the protocol."

`::= { alHostHighCapacityEntry 6 }``alHostHighCapacityOutOverflowOctets OBJECT-TYPE``SYNTAX ZeroBasedCounter32``UNITS "Octets"``MAX-ACCESS read-only``STATUS current``DESCRIPTION`

"The number of times the associated `alHostOutOctets` counter has overflowed."

`::= { alHostHighCapacityEntry 7 }``alHostHighCapacityOutOctets OBJECT-TYPE``SYNTAX ZeroBasedCounter64``UNITS "Octets"``MAX-ACCESS read-only``STATUS current``DESCRIPTION`

"The number of octets transmitted by this address of this protocol type since it was added to the `alHostHighCapacityTable` (excluding framing bits but including FCS octets), excluding those octets in packets that contained errors.

Note this doesn't count just those octets in the particular protocol frames, but includes the entire packet that contained the protocol."

`::= { alHostHighCapacityEntry 8 }`

-- High Capacity extensions for the `alMatrixSDTable`

`alMatrixSDHighCapacityTable OBJECT-TYPE``SYNTAX SEQUENCE OF AlMatrixSDHighCapacityEntry`

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Contains the High Capacity RMON extensions to the RMON-2
alMatrixSDTable."

::= { alMatrix 5 }

alMatrixSDHighCapacityEntry OBJECT-TYPE

SYNTAX AlMatrixSDHighCapacityEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Contains the High Capacity RMON extensions to the RMON-2
alMatrixSDEntry. These objects will be created by the agent
for all alMatrixSDEntries associated with whichever
hlMatrixControlEntries it deems appropriate. (i.e., either all
alMatrixSDHighCapacityEntries associated with a particular
hlMatrixControlEntry will be created, or none of them will
be.)"

INDEX { hlMatrixControlIndex, alMatrixSDTimeMark,
protocolDirLocalIndex,
nlMatrixSDSourceAddress, nlMatrixSDDestAddress,
protocolDirLocalIndex }

::= { alMatrixSDHighCapacityTable 1 }

AlMatrixSDHighCapacityEntry ::= SEQUENCE {

alMatrixSDHighCapacityOverflowPkts ZeroBasedCounter32,

alMatrixSDHighCapacityPkts ZeroBasedCounter64,

alMatrixSDHighCapacityOverflowOctets ZeroBasedCounter32,

alMatrixSDHighCapacityOctets ZeroBasedCounter64

}

alMatrixSDHighCapacityOverflowPkts OBJECT-TYPE

SYNTAX ZeroBasedCounter32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated alMatrixSDPkts
counter has overflowed."

::= { alMatrixSDHighCapacityEntry 1 }

alMatrixSDHighCapacityPkts OBJECT-TYPE

SYNTAX ZeroBasedCounter64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of good packets of this protocol type transmitted from the source address to the destination address since this entry was added to the alMatrixSDHighCapacityTable. Note that this is the number of link-layer packets, so if a single network-layer packet is fragmented into several link-layer frames, this counter is incremented several times."

```
::= { alMatrixSDHighCapacityEntry 2 }
```

alMatrixSDHighCapacityOverflowOctets OBJECT-TYPE

SYNTAX ZeroBasedCounter32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of times the associated alMatrixSDOctets counter has overflowed."

```
::= { alMatrixSDHighCapacityEntry 3 }
```

alMatrixSDHighCapacityOctets OBJECT-TYPE

SYNTAX ZeroBasedCounter64

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets in good packets of this protocol type transmitted from the source address to the destination address since this entry was added to the alMatrixSDHighCapacityTable (excluding framing bits but including FCS octets)."

Note this doesn't count just those octets in the particular protocol frames, but includes the entire packet that contained the protocol."

```
::= { alMatrixSDHighCapacityEntry 4 }
```

-- High Capacity extensions for the alMatrixDSTable

alMatrixDSHighCapacityTable OBJECT-TYPE

SYNTAX SEQUENCE OF AlMatrixDSHighCapacityEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Contains the High Capacity RMON extensions to the RMON-2 alMatrixDSTable."

```
::= { alMatrix 6 }
```

alMatrixDSHighCapacityEntry OBJECT-TYPE

SYNTAX AlMatrixDSHighCapacityEntry

MAX-ACCESS not-accessible

```

STATUS      current
DESCRIPTION
    "Contains the High Capacity RMON extensions to the RMON-2
    alMatrixSDTable. These objects will be created by the agent
    for all alMatrixDSEntries associated with whichever
    hlMatrixControlEntries it deems appropriate. (i.e., either all
    alMatrixDSHighCapacityEntries associated with a particular
    hlMatrixControlEntry will be created, or none of them will
    be.)"
INDEX { hlMatrixControlIndex, alMatrixDSTimeMark,
        protocolDirLocalIndex,
        nlMatrixDSDestAddress, nlMatrixDSSourceAddress,
        protocolDirLocalIndex }
 ::= { alMatrixDSHighCapacityTable 1 }

AlMatrixDSHighCapacityEntry ::= SEQUENCE {
    alMatrixDSHighCapacityOverflowPkts  ZeroBasedCounter32,
    alMatrixDSHighCapacityPkts         ZeroBasedCounter64,
    alMatrixDSHighCapacityOverflowOctets ZeroBasedCounter32,
    alMatrixDSHighCapacityOctets       ZeroBasedCounter64
}

alMatrixDSHighCapacityOverflowPkts OBJECT-TYPE
    SYNTAX      ZeroBasedCounter32
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of times the associated alMatrixDSPkts
        counter has overflowed."
    ::= { alMatrixDSHighCapacityEntry 1 }

alMatrixDSHighCapacityPkts OBJECT-TYPE
    SYNTAX      ZeroBasedCounter64
    UNITS       "Packets"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The number of good packets of this protocol type
        transmitted from the source address to the destination address
        since this entry was added to the alMatrixDSHighCapacityTable.
        Note that this is the number of link-layer packets, so if a
        single network-layer packet is fragmented into several
        link-layer frames, this counter is incremented several times."
    ::= { alMatrixDSHighCapacityEntry 2 }

alMatrixDSHighCapacityOverflowOctets OBJECT-TYPE
    SYNTAX      ZeroBasedCounter32

```

UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of times the associated alMatrixDSOctets
counter has overflowed."
::= { alMatrixDSHighCapacityEntry 3 }

alMatrixDSHighCapacityOctets OBJECT-TYPE

SYNTAX ZeroBasedCounter64
UNITS "Octets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The number of octets in good packets of this protocol type
transmitted from the source address to the destination address
since this entry was added to the alMatrixDSHighCapacityTable
(excluding framing bits but including FCS octets).

Note this doesn't count just those octets in the particular
protocol frames, but includes the entire packet that contained
the protocol."
::= { alMatrixDSHighCapacityEntry 4 }

alMatrixTopNHighCapacityTable OBJECT-TYPE

SYNTAX SEQUENCE OF AlMatrixTopNHighCapacityEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"Contains the High Capacity RMON extensions to the RMON-2
alMatrixTopNTable when alMatrixTopNControlRateBase specifies
a High Capacity TopN Report."
::= { alMatrix 7 }

alMatrixTopNHighCapacityEntry OBJECT-TYPE

SYNTAX AlMatrixTopNHighCapacityEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"Contains the High Capacity RMON extensions to the RMON-2
alMatrixTopNEntry when alMatrixTopNControlRateBase specifies
a High Capacity TopN Report. These objects will be created by
the agent for all alMatrixTopNEntries associated with whichever
alMatrixTopNControlEntries have a alMatrixTopNControlRateBase
that specify a high capacity report."
INDEX { alMatrixTopNControlIndex, alMatrixTopNIndex }
::= { alMatrixTopNHighCapacityTable 1 }


```

AlMatrixTopNHighCapacityEntry ::= SEQUENCE {
    alMatrixTopNHighCapacityProtocolDirLocalIndex      Integer32,
    alMatrixTopNHighCapacitySourceAddress              OCTET STRING,
    alMatrixTopNHighCapacityDestAddress                OCTET STRING,
    alMatrixTopNHighCapacityAppProtocolDirLocalIndex   Integer32,
    alMatrixTopNHighCapacityBasePktRate                Gauge32,
    alMatrixTopNHighCapacityOverflowPktRate            Gauge32,
    alMatrixTopNHighCapacityPktRate                   CounterBasedGauge64,
    alMatrixTopNHighCapacityReverseBasePktRate         Gauge32,
    alMatrixTopNHighCapacityReverseOverflowPktRate     Gauge32,
    alMatrixTopNHighCapacityReversePktRate             CounterBasedGauge64,
    alMatrixTopNHighCapacityBaseOctetRate              Gauge32,
    alMatrixTopNHighCapacityOverflowOctetRate          Gauge32,
    alMatrixTopNHighCapacityOctetRate                  CounterBasedGauge64,
    alMatrixTopNHighCapacityReverseBaseOctetRate       Gauge32,
    alMatrixTopNHighCapacityReverseOverflowOctetRate   Gauge32,
    alMatrixTopNHighCapacityReverseOctetRate           CounterBasedGauge64
}

```

```

alMatrixTopNHighCapacityProtocolDirLocalIndex OBJECT-TYPE
    SYNTAX      Integer32 (1..2147483647)
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The protocolDirLocalIndex of the network layer protocol of
        this entry's network address."
    ::= { alMatrixTopNHighCapacityEntry 1 }

```

```

alMatrixTopNHighCapacitySourceAddress OBJECT-TYPE
    SYNTAX      OCTET STRING
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The network layer address of the source host in this
        conversation.

        This is represented as an octet string with
        specific semantics and length as identified
        by the associated alMatrixTopNProtocolDirLocalIndex.

        For example, if the alMatrixTopNProtocolDirLocalIndex
        indicates an encapsulation of ip, this object is encoded as a
        length octet of 4, followed by the 4 octets of the ip address,
        in network byte order."
    ::= { alMatrixTopNHighCapacityEntry 2 }

```

```

alMatrixTopNHighCapacityDestAddress OBJECT-TYPE
    SYNTAX      OCTET STRING

```

MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The network layer address of the destination host in this conversation.

This is represented as an octet string with specific semantics and length as identified by the associated alMatrixTopNProtocolDirLocalIndex.

For example, if the alMatrixTopNProtocolDirLocalIndex indicates an encapsulation of ip, this object is encoded as a length octet of 4, followed by the 4 octets of the ip address, in network byte order."

::= { alMatrixTopNHighCapacityEntry 3 }

alMatrixTopNHighCapacityAppProtocolDirLocalIndex OBJECT-TYPE

SYNTAX Integer32
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The type of the protocol counted by this entry."

::= { alMatrixTopNHighCapacityEntry 4 }

alMatrixTopNHighCapacityBasePktRate OBJECT-TYPE

SYNTAX Gauge32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The number of packets seen of this protocol from the source host to the destination host during this sampling interval, modulo 2^{32} , counted using the rules for counting the alMatrixSDPkts object."

::= { alMatrixTopNHighCapacityEntry 5 }

alMatrixTopNHighCapacityOverflowPktRate OBJECT-TYPE

SYNTAX Gauge32
UNITS "Packets"
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The number of packets seen of this protocol from the source host to the destination host during this sampling interval, divided by 2^{32} , truncating fractions (i.e., $X \text{ DIV } 2^{32}$), and counted using the rules for counting the alMatrixSDPkts object."

::= { alMatrixTopNHighCapacityEntry 6 }

alMatrixTopNHighCapacityPktRate OBJECT-TYPE

SYNTAX CounterBasedGauge64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of packets seen of this protocol from the source host to the destination host during this sampling interval, counted using the rules for counting the alMatrixSDPkts object.

If the value of alMatrixTopNControlRateBase is alMatrixTopNTerminalsPkts, alMatrixTopNAllPkts, alMatrixTopNTerminalsHighCapacityPkts, or alMatrixTopNAllHighCapacityPkts, this variable will be used to sort this report."

::= { alMatrixTopNHighCapacityEntry 7 }

alMatrixTopNHighCapacityReverseBasePktRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of packets seen of this protocol from the destination host to the source host during this sampling interval, modulo 2^{32} , counted using the rules for counting the alMatrixSDPkts object (note that the corresponding alMatrixSDPkts object selected is the one whose source address is equal to alMatrixTopNDestAddress and whose destination address is equal to alMatrixTopNSourceAddress.)"

::= { alMatrixTopNHighCapacityEntry 8 }

alMatrixTopNHighCapacityReverseOverflowPktRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of packets seen of this protocol from the destination host to the source host during this sampling interval, divided by 2^{32} , truncating fractions (i.e., $X \text{ DIV } 2^{32}$), and counted using the rules for counting the alMatrixSDPkts object (note that the corresponding alMatrixSDPkts object selected is the one whose source address is equal to alMatrixTopNDestAddress and whose destination address is equal to alMatrixTopNSourceAddress.)"

::= { alMatrixTopNHighCapacityEntry 9 }

alMatrixTopNHighCapacityReversePktRate OBJECT-TYPE

SYNTAX CounterBasedGauge64

UNITS "Packets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of packets seen of this protocol from the destination host to the source host during this sampling interval, counted using the rules for counting the alMatrixSDPkts object (note that the corresponding alMatrixSDPkts object selected is the one whose source address is equal to alMatrixTopNDestAddress and whose destination address is equal to alMatrixTopNSourceAddress.)"

::= { alMatrixTopNHighCapacityEntry 10 }

alMatrixTopNHighCapacityBaseOctetRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen of this protocol from the source host to the destination host during this sampling interval, modulo 2^{32} , counted using the rules for counting the alMatrixSDOctets object."

::= { alMatrixTopNHighCapacityEntry 11 }

alMatrixTopNHighCapacityOverflowOctetRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen of this protocol from the source host to the destination host during this sampling interval, divided by 2^{32} , truncating fractions (i.e., $X \text{ DIV } 2^{32}$), and counted using the rules for counting the alMatrixSDOctets object."

::= { alMatrixTopNHighCapacityEntry 12 }

alMatrixTopNHighCapacityOctetRate OBJECT-TYPE

SYNTAX CounterBasedGauge64

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen of this protocol from the source host to the destination host during this sampling interval,

counted using the rules for counting the
alMatrixSDOctets object.

If the value of alMatrixTopNControlRateBase is
alMatrixTopNTerminalsOctets, alMatrixTopNAllOctets,
alMatrixTopNTerminalsHighCapacityOctets, or
alMatrixTopNAllHighCapacityOctets, this variable will be used
to sort this report."

::= { alMatrixTopNHighCapacityEntry 13 }

alMatrixTopNHighCapacityReverseBaseOctetRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen of this protocol from the
destination host to the source host during this sampling
interval, modulo 2^{32} , counted using the rules for counting
the alMatrixSDOctets object (note that the corresponding
alMatrixSDOctets object selected is the one whose source
address is equal to alMatrixTopNDestAddress and whose
destination address is equal to alMatrixTopNSourceAddress.)"

::= { alMatrixTopNHighCapacityEntry 14 }

alMatrixTopNHighCapacityReverseOverflowOctetRate OBJECT-TYPE

SYNTAX Gauge32

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen of this protocol from the
destination host to the source host during this sampling
interval, divided by 2^{32} , truncating fractions (i.e., $X \text{ DIV } 2^{32}$),
and counted using the rules for counting the
alMatrixSDOctets object (note that the corresponding
alMatrixSDOctets object selected is the one whose source
address is equal to alMatrixTopNDestAddress and whose
destination address is equal to alMatrixTopNSourceAddress.)"

::= { alMatrixTopNHighCapacityEntry 15 }

alMatrixTopNHighCapacityReverseOctetRate OBJECT-TYPE

SYNTAX CounterBasedGauge64

UNITS "Octets"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The number of octets seen of this protocol from the
destination host to the source host during this sampling

```

        interval, counted using the rules for counting the
        alMatrixSDOctets object (note that the corresponding
        alMatrixSDOctets object selected is the one whose source
        address is equal to alMatrixTopNDestAddress and whose
        destination address is equal to alMatrixTopNSourceAddress.)"
 ::= { alMatrixTopNHighCapacityEntry 16 }

```

usrHistoryHighCapacityTable OBJECT-TYPE

SYNTAX SEQUENCE OF UsrHistoryHighCapacityEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Contains the High Capacity RMON extensions to the RMON-2
usrHistoryTable."

::= { usrHistory 4 }

usrHistoryHighCapacityEntry OBJECT-TYPE

SYNTAX UsrHistoryHighCapacityEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Contains the High Capacity RMON extensions to the RMON-2
usrHistoryEntry. These objects will be created by the agent
for all usrHistoryEntries associated with whichever
usrHistoryControlEntries it deems appropriate. (i.e., either all
usrHistoryHighCapacityEntries associated with a particular
usrHistoryControlEntry will be created, or none of them will
be.)"

INDEX { usrHistoryControlIndex, usrHistorySampleIndex,
usrHistoryObjectIndex }

::= { usrHistoryHighCapacityTable 1 }

UsrHistoryHighCapacityEntry ::= SEQUENCE {

usrHistoryHighCapacityOverflowAbsValue

Gauge32,

usrHistoryHighCapacityAbsValue

CounterBasedGauge64

}

usrHistoryHighCapacityOverflowAbsValue OBJECT-TYPE

SYNTAX Gauge32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The absolute value (i.e. unsigned value) of the
user-specified statistic during the last sampling period,
divided by 2^32, truncating fractions (i.e., X DIV 2^32).
The value during the current sampling period is not made
available until the period is completed."

To obtain the true value for this sampling interval, the associated instance of `usrHistoryValStatus` should be checked, and `usrHistoryAbsValue` adjusted as necessary.

If the MIB instance could not be accessed during the sampling interval, then this object will have a value of zero and the associated instance of `usrHistoryValStatus` will be set to `'valueNotAvailable(1)'. "`

```
::= { usrHistoryHighCapacityEntry 1 }
```

`usrHistoryHighCapacityAbsValue` OBJECT-TYPE

SYNTAX CounterBasedGauge64

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The absolute value (i.e. unsigned value) of the user-specified statistic during the last sampling period. The value during the current sampling period is not made available until the period is completed.

To obtain the true value for this sampling interval, the associated instance of `usrHistoryValStatus` should be checked, and `usrHistoryHighCapacityAbsValue` adjusted as necessary.

If the MIB instance could not be accessed during the sampling interval, then this object will have a value of zero and the associated instance of `usrHistoryValStatus` will be set to `'valueNotAvailable(1)'. "`

```
::= { usrHistoryHighCapacityEntry 2 }
```

--

-- High Capacity RMON Probe Capabilities

--

`hcrMONCapabilities` OBJECT-TYPE

SYNTAX BITS {

```
mediaIndependentGroup(0),
etherStatsHighCapacityGroup(1),
etherHistoryHighCapacityGroup(2),
hostHighCapacityGroup(3),
hostTopNHighCapacityGroup(4),
matrixHighCapacityGroup(5),
captureBufferHighCapacityGroup(6),
protocolDistributionHighCapacityGroup(7),
nlHostHighCapacityGroup(8),
nlMatrixHighCapacityGroup(9),
nlMatrixTopNHighCapacityGroup(10),
alHostHighCapacityGroup(11),
alMatrixHighCapacityGroup(12),
```

```

        alMatrixTopNHighCapacityGroup(13),
        usrHistoryHighCapacityGroup(14)
    }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "An indication of the High Capacity RMON MIB groups supported
        on at least one interface by this probe."
    ::= { probeConfig 16 }

-- Conformance Macros

hcRmonMIBCompliances OBJECT IDENTIFIER ::= { rmonConformance 6 }
hcRmonMIBGroups      OBJECT IDENTIFIER ::= { rmonConformance 7 }

hcMediaIndependentCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "Describes the requirements for conformance to the
        High Capacity Media Independent Group."
    MODULE -- this module
    MANDATORY-GROUPS { mediaIndependentGroup, hcRMONInformationGroup }
    ::= { hcRmonMIBCompliances 1 }

hcRmon1MIBCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "Describes the requirements for conformance to the High
        Capacity RMON-1 MIB"
    MODULE -- this module
    GROUP etherStatsHighCapacityGroup
    DESCRIPTION
        "The etherStatsHighCapacityGroup is optional but requires
        implementation of the rmonEtherStatsGroup."

    GROUP etherHistoryHighCapacityGroup
    DESCRIPTION
        "The etherHistoryHighCapacityGroup is optional but
        requires implementation of the rmonHistoryControlGroup and
        rmonEthernetHistoryGroup."

    GROUP hostHighCapacityGroup
    DESCRIPTION
        "The hostHighCapacityGroup is mandatory when the
        hostTopNHighCapacityGroup is implemented. This group also
        requires implementation of the rmonHostGroup."

    GROUP hostTopNHighCapacityGroup

```


DESCRIPTION

"The hostTopNHighCapacityGroup is optional but requires implementation of the rmonHostTopNGroup."

GROUP matrixHighCapacityGroup

DESCRIPTION

"The matrixHighCapacityGroup is optional but requires implementation of the rmonMatrixGroup."

GROUP captureBufferHighCapacityGroup

DESCRIPTION

"The captureBufferHighCapacityGroup is optional but requires implementation of the rmonFilterGroup and rmonPacketCaptureGroup."

MODULE RMON-MIB

GROUP rmonEtherStatsGroup

DESCRIPTION

"The RMON Ethernet Statistics Group is mandatory if the etherStatsHighCapacityGroup is implemented."

GROUP rmonHistoryControlGroup

DESCRIPTION

"The RMON History Control Group is mandatory if the etherHistoryHighCapacityGroup is implemented."

GROUP rmonEthernetHistoryGroup

DESCRIPTION

"The RMON Ethernet History Group is mandatory if the etherHistoryHighCapacityGroup is implemented."

GROUP rmonHostGroup

DESCRIPTION

"The RMON Host Group is mandatory if the hostHighCapacityGroup is implemented."

GROUP rmonHostTopNGroup

DESCRIPTION

"The RMON Host Top N Group is mandatory if the hostTopNHighCapacityGroup is implemented."

GROUP rmonMatrixGroup

DESCRIPTION

"The RMON Matrix Group is mandatory if the matrixHighCapacityGroup is implemented."

GROUP rmonFilterGroup

DESCRIPTION

"The RMON Filter Group is mandatory when the captureBufferHighCapacityGroup is implemented."

GROUP rmonPacketCaptureGroup

DESCRIPTION

"The RMON Packet Capture Group is mandatory when the captureBufferHighCapacityGroup is implemented."

::= { hcRmonMIBCompliances 2 }

hcRmon2MIBCompliance MODULE-COMPLIANCE

STATUS current

DESCRIPTION

"Describes the requirements for conformance to the High Capacity RMON-2 MIB"

MODULE -- this module

MANDATORY-GROUPS { protocolDistributionHighCapacityGroup,
nlHostHighCapacityGroup,
nlMatrixHighCapacityGroup,
nlMatrixTopNHighCapacityGroup,
usrHistoryHighCapacityGroup,
hcRMONInformationGroup }

MODULE RMON2-MIB

MANDATORY-GROUPS { protocolDirectoryGroup,
protocolDistributionGroup,
addressMapGroup,
nlHostGroup,
nlMatrixGroup,
usrHistoryGroup,
probeInformationGroup }

GROUP rmon1EnhancementGroup

DESCRIPTION

"The rmon1EnhancementGroup is mandatory for systems which implement RMON [RFC2819]"

::= { hcRmonMIBCompliances 3 }

hcRmon2MIBApplicationLayerCompliance MODULE-COMPLIANCE

STATUS current

DESCRIPTION

"Describes the requirements for conformance to the High Capacity RMON-2 MIB with Application Layer Enhancements."

MODULE -- this module

MANDATORY-GROUPS { protocolDistributionHighCapacityGroup,

nlHostHighCapacityGroup,
nlMatrixHighCapacityGroup,

```

        nlMatrixTopNHighCapacityGroup,
        alHostHighCapacityGroup,
        alMatrixHighCapacityGroup,
        alMatrixTopNHighCapacityGroup,
        usrHistoryHighCapacityGroup,
        hcRMONInformationGroup }

MODULE RMON2-MIB
    MANDATORY-GROUPS { protocolDirectoryGroup,
                        protocolDistributionGroup,
                        addressMapGroup,
                        nlHostGroup,
                        nlMatrixGroup,
                        alHostGroup,
                        alMatrixGroup,
                        usrHistoryGroup,
                        probeInformationGroup }

    GROUP rmon1EnhancementGroup
    DESCRIPTION
        "The rmon1EnhancementGroup is mandatory for systems which
        implement RMON [RFC2819]"
    ::= { hcRmonMIBCompliances 4 }

mediaIndependentGroup OBJECT-GROUP
    OBJECTS {mediaIndependentDataSource,
            mediaIndependentDropEvents,
            mediaIndependentDroppedFrames,
            mediaIndependentInPkts,
            mediaIndependentInOverflowPkts,
            mediaIndependentInHighCapacityPkts,
            mediaIndependentOutPkts,
            mediaIndependentOutOverflowPkts,
            mediaIndependentOutHighCapacityPkts,
            mediaIndependentInOctets,
            mediaIndependentInOverflowOctets,
            mediaIndependentInHighCapacityOctets,
            mediaIndependentOutOctets,
            mediaIndependentOutOverflowOctets,
            mediaIndependentOutHighCapacityOctets,
            mediaIndependentInNUCastPkts,
            mediaIndependentInNUCastOverflowPkts,
            mediaIndependentInNUCastHighCapacityPkts,
            mediaIndependentOutNUCastPkts,
            mediaIndependentOutNUCastOverflowPkts,
            mediaIndependentOutNUCastHighCapacityPkts,
            mediaIndependentInErrors,
            mediaIndependentOutErrors,
            mediaIndependentInputSpeed,

```

```
mediaIndependentOutputSpeed,  
mediaIndependentDuplexMode,  
mediaIndependentDuplexChanges,  
mediaIndependentDuplexLastChange,  
mediaIndependentOwner,  
mediaIndependentStatus }
```

STATUS current

DESCRIPTION

"Collects utilization statistics for any type of network."

::= { hcRmonMIBGroups 1 }

etherStatsHighCapacityGroup OBJECT-GROUP

```
OBJECTS { etherStatsHighCapacityOverflowPkts,  
etherStatsHighCapacityPkts,  
etherStatsHighCapacityOverflowOctets,  
etherStatsHighCapacityOctets,  
etherStatsHighCapacityOverflowPkts64Octets,  
etherStatsHighCapacityPkts64Octets,  
etherStatsHighCapacityOverflowPkts65to127Octets,  
etherStatsHighCapacityPkts65to127Octets,  
etherStatsHighCapacityOverflowPkts128to255Octets,  
etherStatsHighCapacityPkts128to255Octets,  
etherStatsHighCapacityOverflowPkts256to511Octets,  
etherStatsHighCapacityPkts256to511Octets,  
etherStatsHighCapacityOverflowPkts512to1023Octets,  
etherStatsHighCapacityPkts512to1023Octets,  
etherStatsHighCapacityOverflowPkts1024to1518Octets,  
etherStatsHighCapacityPkts1024to1518Octets }
```

STATUS current

DESCRIPTION

"Collects utilization statistics for ethernet networks."

::= { hcRmonMIBGroups 2 }

etherHistoryHighCapacityGroup OBJECT-GROUP

```
OBJECTS { etherHistoryHighCapacityOverflowPkts,  
etherHistoryHighCapacityPkts,  
etherHistoryHighCapacityOverflowOctets,  
etherHistoryHighCapacityOctets }
```

STATUS current

DESCRIPTION

"Collects utilization statistics for ethernet networks."

::= { hcRmonMIBGroups 3 }

hostHighCapacityGroup OBJECT-GROUP

```
OBJECTS { hostHighCapacityInOverflowPkts,  
hostHighCapacityInPkts,  
hostHighCapacityOutOverflowPkts,  
hostHighCapacityOutPkts,
```

```

        hostHighCapacityInOverflowOctets,
        hostHighCapacityInOctets,
        hostHighCapacityOutOverflowOctets,
        hostHighCapacityOutOctets,
        hostTimeHighCapacityInOverflowPkts,
        hostTimeHighCapacityInPkts,
        hostTimeHighCapacityOutOverflowPkts,
        hostTimeHighCapacityOutPkts,
        hostTimeHighCapacityInOverflowOctets,
        hostTimeHighCapacityInOctets,
        hostTimeHighCapacityOutOverflowOctets,
        hostTimeHighCapacityOutOctets }
STATUS    current
DESCRIPTION
    "Collects utilization and error statistics per host."
::= { hcRmonMIBGroups 4 }

hostTopNHighCapacityGroup OBJECT-GROUP
    OBJECTS { hostTopNHighCapacityAddress,
        hostTopNHighCapacityBaseRate,
        hostTopNHighCapacityOverflowRate,
        hostTopNHighCapacityRate }
STATUS    current
DESCRIPTION
    "Prepares sorted reports of utilization and error statistics
    per host."
::= { hcRmonMIBGroups 5 }

matrixHighCapacityGroup OBJECT-GROUP
    OBJECTS { matrixSDHighCapacityOverflowPkts,
        matrixSDHighCapacityPkts,
        matrixSDHighCapacityOverflowOctets,
        matrixSDHighCapacityOctets,
        matrixDSHighCapacityOverflowPkts,
        matrixDSHighCapacityPkts,
        matrixDSHighCapacityOverflowOctets,
        matrixDSHighCapacityOctets }
STATUS    current
DESCRIPTION
    "Collects utilization statistics per conversation."
::= { hcRmonMIBGroups 6 }

captureBufferHighCapacityGroup OBJECT-GROUP
    OBJECTS { captureBufferPacketHighCapacityTime }
STATUS    current
DESCRIPTION
    "Provides finer granularity time stamps."

```

```
::= { hcRmonMIBGroups 7 }
```

```
protocolDistributionHighCapacityGroup OBJECT-GROUP
```

```
OBJECTS { protocolDistStatsHighCapacityOverflowPkts,  
           protocolDistStatsHighCapacityPkts,  
           protocolDistStatsHighCapacityOverflowOctets,  
           protocolDistStatsHighCapacityOctets }
```

```
STATUS current
```

```
DESCRIPTION
```

```
"Collects the relative amounts of octets and packets for the  
different protocols detected on a network segment."
```

```
::= { hcRmonMIBGroups 8 }
```

```
nlHostHighCapacityGroup OBJECT-GROUP
```

```
OBJECTS { nlHostHighCapacityInOverflowPkts,  
           nlHostHighCapacityInPkts,  
           nlHostHighCapacityOutOverflowPkts,  
           nlHostHighCapacityOutPkts,  
           nlHostHighCapacityInOverflowOctets,  
           nlHostHighCapacityInOctets,  
           nlHostHighCapacityOutOverflowOctets,  
           nlHostHighCapacityOutOctets }
```

```
STATUS current
```

```
DESCRIPTION
```

```
"Counts the amount of traffic sent from and to each network  
address discovered by the probe."
```

```
::= { hcRmonMIBGroups 9 }
```

```
nlMatrixHighCapacityGroup OBJECT-GROUP
```

```
OBJECTS { nlMatrixSDHighCapacityOverflowPkts,  
           nlMatrixSDHighCapacityPkts,  
           nlMatrixSDHighCapacityOverflowOctets,  
           nlMatrixSDHighCapacityOctets,  
           nlMatrixDSHighCapacityOverflowPkts,  
           nlMatrixDSHighCapacityPkts,  
           nlMatrixDSHighCapacityOverflowOctets,  
           nlMatrixDSHighCapacityOctets }
```

```
STATUS current
```

```
DESCRIPTION
```

```
"Counts the amount of traffic sent between each pair of  
network addresses discovered by the probe."
```

```
::= { hcRmonMIBGroups 10 }
```

```
nlMatrixTopNHighCapacityGroup OBJECT-GROUP
```

```
OBJECTS { nlMatrixTopNHighCapacityProtocolDirLocalIndex,  
           nlMatrixTopNHighCapacitySourceAddress,  
           nlMatrixTopNHighCapacityDestAddress,  
           nlMatrixTopNHighCapacityBasePktRate,
```

```

nlMatrixTopNHighCapacityOverflowPktRate,
nlMatrixTopNHighCapacityPktRate,
nlMatrixTopNHighCapacityReverseBasePktRate,
nlMatrixTopNHighCapacityReverseOverflowPktRate,
nlMatrixTopNHighCapacityReversePktRate,
nlMatrixTopNHighCapacityBaseOctetRate,
nlMatrixTopNHighCapacityOverflowOctetRate,
nlMatrixTopNHighCapacityOctetRate,
nlMatrixTopNHighCapacityReverseBaseOctetRate,
nlMatrixTopNHighCapacityReverseOverflowOctetRate,
nlMatrixTopNHighCapacityReverseOctetRate }

```

STATUS current

DESCRIPTION

"Prepares sorted reports of the amount of traffic sent between each pair of network addresses discovered by the probe."

```
::= { hcRmonMIBGroups 11 }
```

alHostHighCapacityGroup OBJECT-GROUP

```

OBJECTS { alHostHighCapacityInOverflowPkts,
          alHostHighCapacityInPkts,
          alHostHighCapacityOutOverflowPkts,
          alHostHighCapacityOutPkts,
          alHostHighCapacityInOverflowOctets,
          alHostHighCapacityInOctets,
          alHostHighCapacityOutOverflowOctets,
          alHostHighCapacityOutOctets }

```

STATUS current

DESCRIPTION

"Counts the amount of traffic, by protocol, sent from and to each network address discovered by the probe."

```
::= { hcRmonMIBGroups 12 }
```

alMatrixHighCapacityGroup OBJECT-GROUP

```

OBJECTS { alMatrixSDHighCapacityOverflowPkts,
          alMatrixSDHighCapacityPkts,
          alMatrixSDHighCapacityOverflowOctets,
          alMatrixSDHighCapacityOctets,
          alMatrixDSHighCapacityOverflowPkts,
          alMatrixDSHighCapacityPkts,
          alMatrixDSHighCapacityOverflowOctets,
          alMatrixDSHighCapacityOctets }

```

STATUS current

DESCRIPTION

"Counts the amount of traffic, by protocol, sent between each pair of network addresses discovered by the probe."

```
::= { hcRmonMIBGroups 13 }
```

```
alMatrixTopNHighCapacityGroup OBJECT-GROUP
  OBJECTS { alMatrixTopNHighCapacityProtocolDirLocalIndex,
    alMatrixTopNHighCapacitySourceAddress,
    alMatrixTopNHighCapacityDestAddress,
    alMatrixTopNHighCapacityAppProtocolDirLocalIndex,
    alMatrixTopNHighCapacityBasePktRate,
    alMatrixTopNHighCapacityOverflowPktRate,
    alMatrixTopNHighCapacityPktRate,
    alMatrixTopNHighCapacityReverseBasePktRate,
    alMatrixTopNHighCapacityReverseOverflowPktRate,
    alMatrixTopNHighCapacityReversePktRate,
    alMatrixTopNHighCapacityBaseOctetRate,
    alMatrixTopNHighCapacityOverflowOctetRate,
    alMatrixTopNHighCapacityOctetRate,
    alMatrixTopNHighCapacityReverseBaseOctetRate,
    alMatrixTopNHighCapacityReverseOverflowOctetRate,
    alMatrixTopNHighCapacityReverseOctetRate }
  STATUS current
  DESCRIPTION
    "Prepares sorted reports of the amount of traffic per protocol
    sent between each pair of network addresses discovered by the
    probe."
  ::= { hcRmonMIBGroups 14 }

usrHistoryHighCapacityGroup OBJECT-GROUP
  OBJECTS { usrHistoryHighCapacityOverflowAbsValue,
    usrHistoryHighCapacityAbsValue }
  STATUS current
  DESCRIPTION
    "Provides user-defined collection of historical information
    from MIB objects on the probe with scalability to statistics
    from high-capacity networks."
  ::= { hcRmonMIBGroups 15 }

hcrMONInformationGroup OBJECT-GROUP
  OBJECTS { hcrMONCapabilities }
  STATUS current
  DESCRIPTION
    "An indication of the high capacity RMON groups supported on
    at least one interface by this probe."
  ::= { hcRmonMIBGroups 16 }

END
```


6. Security Considerations

In order to implement this MIB, a probe must capture all packets on the locally-attached network, including packets between third parties. These packets are analyzed to collect network addresses, protocol usage information, and conversation statistics. Data of this nature may be considered sensitive in some environments. In such environments the administrator may wish to restrict SNMP access to the probe.

A probe implementing this MIB is likely to also implement RMON [RFC 2819], which includes functions for returning the contents of captured packets, potentially including sensitive user data or passwords. It is recommended that SNMP access to these functions be restricted.

There are a number of management objects defined in this MIB that have a MAX-ACCESS clause of read-write and/or read-create. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations.

SNMPv1 by itself is not a secure environment. Even if the network itself is secure (for example by using IPSec), even then, there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB.

It is recommended that the implementers consider the security features as provided by the SNMPv3 framework. Specifically, the use of the User-based Security Model RFC 2574 [RFC2574] and the View-based Access Control Model RFC 2575 [RFC2575] is recommended.

It is then a customer/user responsibility to ensure that the SNMP entity giving access to an instance of this MIB, is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

7. Acknowledgments

This document was produced by the IETF Remote Network Monitoring Working Group.

8. References

- [1] Harrington, D., Presuhn, R. and B. Wijnen, "An Architecture for Describing SNMP Management Frameworks", RFC 2571, April 1999.

- [2] Rose, M. and K. McCloghrie, "Structure and Identification of Management Information for TCP/IP-based Internets", STD 16, RFC 1155, May 1990.
- [3] Rose, M. and K. McCloghrie, "Concise MIB Definitions", STD 16, RFC 1212, March 1991.
- [4] Rose, M., "A Convention for Defining Traps for use with the SNMP", RFC 1215, March 1991.
- [5] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Structure of Management Information Version 2 (SMIv2)", STD 58, RFC 2578, April 1999.
- [6] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Textual Conventions for SMIv2", STD 58, RFC 2579, April 1999.
- [7] McCloghrie, K., Perkins, D., Schoenwaelder, J., Case, J., Rose, M. and S. Waldbusser, "Conformance Statements for SMIv2", STD 58, RFC 2580, April 1999.
- [8] Case, J., Fedor, M., Schoffstall, M. and J. Davin, "Simple Network Management Protocol", STD 15, RFC 1157, May 1990.
- [9] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Introduction to Community-based SNMPv2", RFC 1901, January 1996.
- [10] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Transport Mappings for Version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1906, January 1996.
- [11] Case, J., Harrington D., Presuhn R. and B. Wijnen, "Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)", RFC 2572, April 1999.
- [12] Blumenthal, U. and B. Wijnen, "User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)", RFC 2574, April 1999.
- [13] Case, J., McCloghrie, K., Rose, M. and S. Waldbusser, "Protocol Operations for Version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1905, January 1996.
- [14] Levi, D., Meyer, P. and B. Stewart, "SNMPv3 Applications", RFC 2573, April 1999.

- [15] Wijnen, B., Presuhn, R. and K. McCloghrie, "View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)", RFC 2575, April 1999.
- [16] McCloghrie, K. and M. Rose, Editors, "Management Information Base for Network Management of TCP/IP-based internets: MIB-II", STD 17, RFC 1213, March 1991.
- [17] McCloghrie, K. and F. Kastenholz, "The Interfaces Group MIB", RFC 2863, June 2000.
- [18] Waldbusser, S., "Remote Network Monitoring MIB", STD 59, RFC 2819, May 2000.
- [19] Waldbusser, S., "Token Ring Extensions to the Remote Network Monitoring MIB", RFC 1513, September 1993.
- [20] Waldbusser, S., "Remote Network Monitoring Management Information Base Version 2 using SMIV2", RFC 2021, January 1997.
- [21] Case, J., Mundy, R., Partain, D. and B. Stewart, "Introduction to Version 3 of the Internet-standard Network Management Framework", RFC 2570, April 1999.

9. Notices

The IETF takes no position regarding the validity or scope of any intellectual property or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; neither does it represent that it has made any effort to identify any such rights. Information on the IETF's procedures with respect to rights in standards-track and standards-related documentation can be found in BCP-11. Copies of claims of rights made available for publication and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementors or users of this specification can be obtained from the IETF Secretariat.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights which may cover technology that may be required to practice this standard. Please address the information to the IETF Executive Director.

10. Author's Address

Steve Waldbusser

Phone: +1-650-948-6500

Fax: +1-650-745-0671

EMail: waldbusser@nextbeacon.com

11. Full Copyright Statement

Copyright (C) The Internet Society (2002). All Rights Reserved.

This document and translations of it may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, such as by removing the copyright notice or references to the Internet Society or other Internet organizations, except as needed for the purpose of developing Internet standards in which case the procedures for copyrights defined in the Internet Standards process must be followed, or as required to translate it into languages other than English.

The limited permissions granted above are perpetual and will not be revoked by the Internet Society or its successors or assigns.

This document and the information contained herein is provided on an "AS IS" basis and THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Acknowledgement

Funding for the RFC Editor function is currently provided by the Internet Society.

