

Power Ethernet MIB

Status of this Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Copyright Notice

Copyright (C) The Internet Society (2003). All Rights Reserved.

Abstract

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. This document proposes an extension to the Ethernet-like Interfaces MIB with a set of objects for managing Power Sourcing Equipment (PSE).

Table of Contents

1. Introduction	2
2. The Internet-Standard Management Framework	2
3. Overview	2
4. MIB Structure.	3
5. Definitions.	3
6. Acknowledgements	16
7. References	16
7.1. Normative References	16
7.2. Informative References	17
8. Intellectual Property Statement.	17
9. Security Considerations.	18
10. Authors' Addresses	19
11. Full Copyright Statement	20

1. Introduction

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. In particular, it defines a set of MIB objects to manage Power Ethernet [IEEE-802.3af] Power Sourcing Equipment (PSE).

The key words "MUST", "MUST NOT", "REQUIRED", "SHALL", "SHALL NOT", "SHOULD", "SHOULD NOT", "RECOMMENDED", "MAY", and "OPTIONAL" in this document are to be interpreted as described in [RFC2119].

2. The Internet-Standard Management Framework

For a detailed overview of the documents that describe the current Internet-Standard Management Framework, please refer to section 7 of RFC 3410 [RFC3410].

Managed objects are accessed via a virtual information store, termed the Management Information Base or MIB. MIB objects are generally accessed through the Simple Network Management Protocol (SNMP). Objects in the MIB are defined using the mechanisms defined in the Structure of Management Information (SMI). This memo specifies a MIB module that is compliant to the SMIV2, which is described in STD 58, RFC 2578 [RFC2578], STD 58, RFC 2579 [RFC2579] and STD 58, RFC 2580 [RFC2580].

3. Overview

The emergence of IP telephony as an application that allows voice applications to be run over the same infrastructure as data applications has led to the emergence of Ethernet IP phones, which have similar functions and characteristics as traditional phones. Powering the phone with the same cable used for signal transfer is one of the functions that are being taken as granted. The IEEE 802.3 Working Group has initiated standardization on this subject, currently known as the IEEE 802.3af work [IEEE-802.3af].

The IEEE 802.3af WG did not define a full management interface, but only the hardware registers that will allow for management interfaces to be built for a powered Ethernet device. The MIB module defined in this document extends the Ethernet-like Interfaces MIB [RFC3635] with the management objects required for the management of the powered Ethernet devices and ports.

The following abbreviations are defined in [IEEE-802.3af] and will be used with the same significance in this document:

PSE - Power Sourcing Equipment;

PD - Powered Device

4. MIB Structure

These MIB objects are categorized into three MIB groups.

The pethPsePortTable defines the objects used for configuring and describing the status of ports on a PSE device. Examples of PSE devices are Ethernet switches that support power Ethernet and mid-span boxes.

The pethMainPseObjects MIB group defines the management objects for a managed main power source in a PSE device. Ethernet switches are one example of boxes that would support these objects.

The pethNotificationControlTable includes objects that control the transmission of notifications from the agent to a management application.

5. Definitions

POWER-ETHERNET-MIB DEFINITIONS ::= BEGIN

IMPORTS

```
MODULE-IDENTITY, mib-2, OBJECT-TYPE, Integer32,
Gauge32, Counter32, NOTIFICATION-TYPE
    FROM SNMPv2-SMI
TruthValue
    FROM SNMPv2-TC
MODULE-COMPLIANCE, OBJECT-GROUP, NOTIFICATION-GROUP
    FROM SNMPv2-CONF

    SnmpAdminString
        FROM SNMP-FRAMEWORK-MIB;
```

powerEthernetMIB MODULE-IDENTITY

```
LAST-UPDATED      "200311240000Z"  -- November 24, 2003
ORGANIZATION "IETF Ethernet Interfaces and Hub MIB
              Working Group"
```

CONTACT-INFO

"

WG Charter:

<http://www.ietf.org/html.charters/hubmib-charter.html>

Mailing lists:

General Discussion: hubmib@ietf.orgTo Subscribe: hubmib-requests@ietf.org

In Body: subscribe your_email_address

Chair: Dan Romascanu

Avaya

Tel: +972-3-645-8414

Email: dromasca@avaya.com

Editor: Avi Berger

PowerDsine Inc.

Tel: 972-9-7755100 Ext 307

Fax: 972-9-7755120

E-mail: avib@PowerDsine.com

"

DESCRIPTION

"The MIB module for managing Power Source Equipment (PSE) working according to the IEEE 802.af Powered Ethernet (DTE Power via MDI) standard.

The following terms are used throughout this MIB module. For complete formal definitions, the IEEE 802.3 standards should be consulted wherever possible:

Group - A recommended, but optional, entity defined by the IEEE 802.3 management standard, in order to support a modular numbering scheme. The classical example allows an implementor to represent field-replaceable units as groups of ports, with the port numbering matching the modular hardware implementation.

Port - This entity identifies the port within the group for which this entry contains information. The numbering scheme for ports is implementation specific.

Copyright (c) The Internet Society (2003). This version of this MIB module is part of RFC 3621; See the RFC itself for full legal notices."

```

REVISION      "200311240000Z"  -- November 24, 2003
DESCRIPTION   "Initial version, published as RFC 3621."
 ::= { mib-2 105 }

```

```

pethNotifications OBJECT IDENTIFIER ::= { powerEthernetMIB 0 }
pethObjects        OBJECT IDENTIFIER ::= { powerEthernetMIB 1 }
pethConformance    OBJECT IDENTIFIER ::= { powerEthernetMIB 2 }

```

-- PSE Objects

```

pethPsePortTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF PethPsePortEntry
    MAX-ACCESS   not-accessible
    STATUS      current
    DESCRIPTION
        "A table of objects that display and control the power
         characteristics of power Ethernet ports on a Power Source
         Entity (PSE) device. This group will be implemented in
         managed power Ethernet switches and mid-span devices.
         Values of all read-write objects in this table are
         persistent at restart/reboot."
    ::= { pethObjects 1 }

```

```

pethPsePortEntry OBJECT-TYPE
    SYNTAX      PethPsePortEntry
    MAX-ACCESS   not-accessible
    STATUS      current
    DESCRIPTION
        "A set of objects that display and control the power
         characteristics of a power Ethernet PSE port."
    INDEX       { pethPsePortGroupIndex , pethPsePortIndex }
    ::= { pethPsePortTable 1 }

```

```

PethPsePortEntry ::= SEQUENCE {
    pethPsePortGroupIndex
        Integer32,
    pethPsePortIndex
        Integer32,
    pethPsePortAdminEnable
        TruthValue,
    pethPsePortPowerPairsControlAbility
        TruthValue,
    pethPsePortPowerPairs
        INTEGER,
    pethPsePortDetectionStatus
        INTEGER,
    pethPsePortPowerPriority
        INTEGER,
}

```

```

    pethPsePortMPSAbsentCounter
        Counter32,
    pethPsePortType
        SnmpAdminString,
    pethPsePortPowerClassifications
        INTEGER,
    pethPsePortInvalidSignatureCounter
        Counter32,
    pethPsePortPowerDeniedCounter
        Counter32,
    pethPsePortOverLoadCounter
        Counter32,
    pethPsePortShortCounter
        Counter32
}

pethPsePortGroupIndex OBJECT-TYPE
    SYNTAX      Integer32 (1..2147483647)
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This variable uniquely identifies the group
        containing the port to which a power Ethernet PSE is
        connected. Group means box in the stack, module in a
        rack and the value 1 MUST be used for non-modular devices.
        Furthermore, the same value MUST be used in this variable,
        pethMainPseGroupIndex, and pethNotificationControlGroupIndex
        to refer to a given box in a stack or module in the rack."
    ::= { pethPsePortEntry 1 }

pethPsePortIndex OBJECT-TYPE
    SYNTAX      Integer32 (1..2147483647)
    MAX-ACCESS  not-accessible
    STATUS      current
    DESCRIPTION
        "This variable uniquely identifies the power Ethernet PSE
        port within group pethPsePortGroupIndex to which the
        power Ethernet PSE entry is connected."
    ::= { pethPsePortEntry 2 }

pethPsePortAdminEnable OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "true (1) An interface which can provide the PSE functions.
        false(2) The interface will act as it would if it had no PSE
        function."

```

REFERENCE

"IEEE Std 802.3af Section 30.9.1.1.2 aPSEAdminState"
 ::= { pethPsePortEntry 3 }

pethPsePortPowerPairsControlAbility OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Describes the capability of controlling the power pairs functionality to switch pins for sourcing power. The value true indicate that the device has the capability to control the power pairs. When false the PSE Pinout Alternative used cannot be controlled through the PethPsePortAdminEnable attribute."

REFERENCE

"IEEE Std 802.3af Section 30.9.1.1.3
 aPSEPowerPairsControlAbility"
 ::= { pethPsePortEntry 4 }

pethPsePortPowerPairs OBJECT-TYPE

SYNTAX INTEGER {
 signal(1),
 spare(2)
 }

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Describes or controls the pairs in use. If the value of pethPsePortPowerPairsControl is true, this object is writable.

A value of signal(1) means that the signal pairs only are in use.

A value of spare(2) means that the spare pairs only are in use."

REFERENCE

"IEEE Std 802.3af Section 30.9.1.1.4 aPSEPowerPairs"
 ::= { pethPsePortEntry 5 }

pethPsePortDetectionStatus OBJECT-TYPE

SYNTAX INTEGER {
 disabled(1),
 searching(2),
 deliveringPower(3),
 fault(4),
 test(5),
 otherFault(6)
 }

MAX-ACCESS read-only
 STATUS current
 DESCRIPTION

"Describes the operational status of the port PD detection.
 A value of disabled(1)- indicates that the PSE State diagram is in the state DISABLED.
 A value of deliveringPower(3) - indicates that the PSE State diagram is in the state POWER_ON for a duration greater than tlim max (see IEEE Std 802.3af Table 33-5 tlim).
 A value of fault(4) - indicates that the PSE State diagram is in the state TEST_ERROR.
 A value of test(5) - indicates that the PSE State diagram is in the state TEST_MODE.
 A value of otherFault(6) - indicates that the PSE State diagram is in the state IDLE due to the variable error_conditions.
 A value of searching(2)- indicates the PSE State diagram is in a state other than those listed above."

REFERENCE

"IEEE Std 802.3af Section 30.9.1.1.5
 aPSEPowerDetectionStatus"

::= { pethPsePortEntry 6 }

pethPsePortPowerPriority OBJECT-TYPE

SYNTAX INTEGER {
 critical(1),
 high(2),
 low(3)
 }

MAX-ACCESS read-write
 STATUS current
 DESCRIPTION

"This object controls the priority of the port from the point of view of a power management algorithm. The priority that is set by this variable could be used by a control mechanism that prevents over current situations by disconnecting first ports with lower power priority. Ports that connect devices critical to the operation of the network - like the E911 telephones ports - should be set to higher priority."

::= { pethPsePortEntry 7 }

pethPsePortMPSAbsentCounter OBJECT-TYPE

SYNTAX Counter32
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION

"This counter is incremented when the PSE state diagram transitions directly from the state POWER_ON to the

state IDLE due to tmpdo_timer_done being asserted."

REFERENCE

"IEEE Std 802.3af Section 30.9.1.1.11
apSEMPSAbsentCounter"
::= { pethPsePortEntry 8 }

pethPsePortType OBJECT-TYPE
SYNTAX SnmpAdminString
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"A manager will set the value of this variable to indicate
the type of powered device that is connected to the port.
The default value supplied by the agent if no value has
ever been set should be a zero-length octet string."
::= { pethPsePortEntry 9 }

pethPsePortPowerClassifications OBJECT-TYPE
SYNTAX INTEGER {
 class0(1),
 class1(2),
 class2(3),
 class3(4),
 class4(5)
}
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Classification is a way to tag different terminals on the
Power over LAN network according to their power consumption.
Devices such as IP telephones, WLAN access points and others,
will be classified according to their power requirements.

The meaning of the classification labels is defined in the
IEEE specification.

This variable is valid only while a PD is being powered,
that is, while the attribute pethPsePortDetectionStatus
is reporting the enumeration deliveringPower."
REFERENCE
"IEEE Std 802.3af Section 30.9.1.1.6
apSEPowerClassification"
::= { pethPsePortEntry 10 }

pethPsePortInvalidSignatureCounter OBJECT-TYPE
SYNTAX Counter32
MAX-ACCESS read-only
STATUS current

DESCRIPTION

"This counter is incremented when the PSE state diagram enters the state SIGNATURE_INVALID."

REFERENCE

"IEEE Std 802.3af Section 30.9.1.1.7
aPSEInvalidSignatureCounter"

::= { pethPsePortEntry 11 }

pethPsePortPowerDeniedCounter OBJECT-TYPE

SYNTAX Counter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This counter is incremented when the PSE state diagram enters the state POWER_DENIED."

REFERENCE

"IEEE Std 802.3af Section 30.9.1.1.8
aPSEPowerDeniedCounter"

::= { pethPsePortEntry 12 }

pethPsePortOverLoadCounter OBJECT-TYPE

SYNTAX Counter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This counter is incremented when the PSE state diagram enters the state ERROR_DELAY_OVER."

REFERENCE

"IEEE Std 802.3af Section 30.9.1.1.9
aPSEOverLoadCounter"

::= { pethPsePortEntry 13 }

pethPsePortShortCounter OBJECT-TYPE

SYNTAX Counter32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This counter is incremented when the PSE state diagram enters the state ERROR_DELAY_SHORT."

REFERENCE

"IEEE Std 802.3af Section 30.9.1.1.10
aPSEShortCounter"

::= { pethPsePortEntry 14 }

-- Main PSE Objects

pethMainPseObjects OBJECT IDENTIFIER ::= { pethObjects 3 }

pethMainPseTable OBJECT-TYPE

SYNTAX SEQUENCE OF PethMainPseEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A table of objects that display and control attributes of the main power source in a PSE device. Ethernet switches are one example of boxes that would support these objects.

Values of all read-write objects in this table are persistent at restart/reboot."

```
::= { pethMainPseObjects 1 }
```

pethMainPseEntry OBJECT-TYPE

SYNTAX PethMainPseEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"A set of objects that display and control the Main power of a PSE. "

INDEX { pethMainPseGroupIndex }

```
::= { pethMainPseTable 1 }
```

```
PethMainPseEntry ::= SEQUENCE {
```

```
  pethMainPseGroupIndex
```

```
    Integer32,
```

```
  pethMainPsePower
```

```
    Gauge32 ,
```

```
  pethMainPseOperStatus
```

```
    INTEGER,
```

```
  pethMainPseConsumptionPower
```

```
    Gauge32,
```

```
  pethMainPseUsageThreshold
```

```
    Integer32
```

```
}
```

pethMainPseGroupIndex OBJECT-TYPE

SYNTAX Integer32 (1..2147483647)

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This variable uniquely identifies the group to which power Ethernet PSE is connected. Group means (box in the stack, module in a rack) and the value 1 MUST be used for non-modular devices. Furthermore, the same value MUST be used in this variable, pethPsePortGroupIndex, and pethNotificationControlGroupIndex to refer to a given box in a stack or module in a rack."

```
::= { pethMainPseEntry 1 }
```

```

pethMainPsePower OBJECT-TYPE
    SYNTAX      Gauge32  (1..65535)
    UNITS       "Watts"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The nominal power of the PSE expressed in Watts."
    ::= { pethMainPseEntry 2 }

```

```

pethMainPseOperStatus OBJECT-TYPE
    SYNTAX INTEGER {
        on(1),
        off(2),
        faulty(3)
    }
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The operational status of the main PSE."
    ::= { pethMainPseEntry 3 }

```

```

pethMainPseConsumptionPower OBJECT-TYPE
    SYNTAX      Gauge32
    UNITS       "Watts"
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "Measured usage power expressed in Watts."
    ::= { pethMainPseEntry 4 }

```

```

pethMainPseUsageThreshold OBJECT-TYPE
    SYNTAX      Integer32  (1..99)
    UNITS       "%"
    MAX-ACCESS  read-write
    STATUS      current
    DESCRIPTION
        "The usage threshold expressed in percents for
         comparing the measured power and initiating
         an alarm if the threshold is exceeded."
    ::= { pethMainPseEntry 5 }

```

-- Notification Control Objects

```

pethNotificationControl          OBJECT IDENTIFIER ::= { pethObjects 4 }

```

```

pethNotificationControlTable OBJECT-TYPE
    SYNTAX      SEQUENCE OF PethNotificationControlEntry
    MAX-ACCESS  not-accessible

```

```

STATUS      current
DESCRIPTION
    "A table of objects that display and control the
    Notification on a PSE device.
    Values of all read-write objects in this table are
    persistent at restart/reboot."
::= { pethNotificationControl 1 }

pethNotificationControlEntry OBJECT-TYPE
    SYNTAX      PethNotificationControlEntry
    MAX-ACCESS   not-accessible
    STATUS      current
    DESCRIPTION
        "A set of objects that control the Notification events."
    INDEX       { pethNotificationControlGroupIndex }
    ::= { pethNotificationControlTable 1 }

PethNotificationControlEntry ::= SEQUENCE {
    pethNotificationControlGroupIndex
        Integer32,
    pethNotificationControlEnable
        TruthValue
}

pethNotificationControlGroupIndex OBJECT-TYPE
    SYNTAX      Integer32 (1..2147483647)
    MAX-ACCESS   not-accessible
    STATUS      current
    DESCRIPTION
        "This variable uniquely identifies the group. Group
        means box in the stack, module in a rack and the value
        1 MUST be used for non-modular devices. Furthermore,
        the same value MUST be used in this variable,
        pethPsePortGroupIndex, and
        pethMainPseGroupIndex to refer to a given box in a
        stack or module in a rack. "
    ::= { pethNotificationControlEntry 1 }

pethNotificationControlEnable OBJECT-TYPE
    SYNTAX      TruthValue
    MAX-ACCESS   read-write
    STATUS      current
    DESCRIPTION
        "This object controls, on a per-group basis, whether
        or not notifications from the agent are enabled. The
        value true(1) means that notifications are enabled; the
        value false(2) means that they are not."
    ::= { pethNotificationControlEntry 2 }

```

```
--
--
--
```

```
-- Notifications Section
```

```
pethPsePortOnOffNotification NOTIFICATION-TYPE
  OBJECTS      { pethPsePortDetectionStatus }
  STATUS       current
  DESCRIPTION
    " This Notification indicates if Pse Port is delivering or
      not power to the PD. This Notification SHOULD be sent on
      every status change except in the searching mode.
      At least 500 msec must elapse between notifications
      being emitted by the same object instance."
  ::= { pethNotifications 1 }
```

```
pethMainPowerUsageOnNotification NOTIFICATION-TYPE
  OBJECTS      { pethMainPseConsumptionPower }
  STATUS       current
  DESCRIPTION
    " This Notification indicate PSE Threshold usage
      indication is on, the usage power is above the
      threshold. At least 500 msec must elapse between
      notifications being emitted by the same object
      instance."
  ::= { pethNotifications 2 }
```

```
pethMainPowerUsageOffNotification NOTIFICATION-TYPE
  OBJECTS      { pethMainPseConsumptionPower }
  STATUS       current
  DESCRIPTION
    " This Notification indicates PSE Threshold usage indication
      off, the usage power is below the threshold.
      At least 500 msec must elapse between notifications being
      emitted by the same object instance."
  ::= { pethNotifications 3 }
```

```
--
--
```

```
-- Conformance Section
```

```
--
pethCompliances OBJECT IDENTIFIER ::= { pethConformance 1 }
pethGroups      OBJECT IDENTIFIER ::= { pethConformance 2 }
```

```
pethCompliance MODULE-COMPLIANCE
  STATUS       current
  DESCRIPTION
    "Describes the requirements for conformance to the
    Power Ethernet MIB."
```

```

MODULE -- this module
    MANDATORY-GROUPS { pethPsePortGroup,
                        pethPsePortNotificationGroup,
                        pethNotificationControlGroup
                      }
    GROUP    pethMainPseGroup
    DESCRIPTION
        "The pethMainPseGroup is mandatory for PSE systems
         that implement a main power supply."
    GROUP    pethMainPowerNotificationGroup
    DESCRIPTION
        "The pethMainPowerNotificationGroup is mandatory for
         PSE systems that implement a main power supply."
    ::= { pethCompliances 1 }

pethPsePortGroup OBJECT-GROUP
    OBJECTS {
        pethPsePortAdminEnable,
        pethPsePortPowerPairsControlAbility,
        pethPsePortPowerPairs,
        pethPsePortDetectionStatus,
        pethPsePortPowerPriority,
        pethPsePortMPSAbsentCounter,
        pethPsePortInvalidSignatureCounter,
        pethPsePortPowerDeniedCounter,
        pethPsePortOverLoadCounter,
        pethPsePortShortCounter,
        pethPsePortType,
        pethPsePortPowerClassifications
    }
    STATUS    current
    DESCRIPTION
        "PSE Port objects."
    ::= { pethGroups 1 }

pethMainPseGroup OBJECT-GROUP
    OBJECTS {
        pethMainPsePower,
        pethMainPseOperStatus,
        pethMainPseConsumptionPower,
        pethMainPseUsageThreshold
    }
    STATUS    current
    DESCRIPTION
        "Main PSE Objects. "
    ::= { pethGroups 2 }

pethNotificationControlGroup OBJECT-GROUP

```

```
OBJECTS {
    pethNotificationControlEnable
}
STATUS    current
DESCRIPTION
    "Notification Control  Objects.  "
 ::= { pethGroups 3 }

pethPsePortNotificationGroup NOTIFICATION-GROUP
NOTIFICATIONS { pethPsePortOnOffNotification}
STATUS        current
DESCRIPTION   "Pse Port Notifications."
 ::= { pethGroups 4 }

pethMainPowerNotificationGroup NOTIFICATION-GROUP
NOTIFICATIONS { pethMainPowerUsageOnNotification,
                pethMainPowerUsageOffNotification}
STATUS        current
DESCRIPTION   "Main PSE Notifications."
 ::= { pethGroups 5 }

END
```

6. Acknowledgements

This document is the product of the Ethernet Interfaces and Hub MIB WG. The authors would like to recognize the special contributions of C.M. Heard and David Law.

7. References

7.1. Normative References

- [RFC2026] Bradner, S., "The Internet Standards Process - Revision 3", BCP 9, RFC 2026, October 1996.
- [RFC2578] McCloghrie, K., Perkins, D. and J. Schoenwaelder, "Structure of Management Information Version 2 (SMIv2)", STD 58, RFC 2578, April 1999.
- [RFC2579] McCloghrie, K., Perkins, D. and J. Schoenwaelder, "Textual Conventions for SMIv2", STD 58, RFC 2579, April 1999.
- [RFC2580] McCloghrie, K., Perkins, D. and J. Schoenwaelder, "Conformance Statements for SMIv2", STD 58, RFC 2580, April 1999.

- [RFC2119] Bradner, S., "Key words for use in RFCs to Indicate Requirement Levels", BCP 14, RFC 2119, March 1997.
- [RFC3635] Flick, J., "Definitions of Managed Objects for the Ethernet-like Interface Types", RFC 3635, September 2003.
- [RFC3411] Harrington, D., Presuhn, R. and B. Wijnen, "An Architecture for Describing Simple Network Management Protocol (SNMP) Management Frameworks", STD 62, RFC 3411, December 2002.
- [IEEE-802.3af] IEEE 802.3 Working Group, "IEEE Std 802.3af-2003 - Data Terminal Equipment (DTE) Power via Media Dependent Interface (MDI)", July 2003.

7.2. Informative References

- [RFC3410] Case, J., Mundy, R., Partain, D. and B. Stewart, "Introduction and Applicability Statements for Internet-Standard Management Framework", RFC 3410, December 2002.

8. Intellectual Property Statement

The IETF takes no position regarding the validity or scope of any intellectual property or other rights that might be claimed to pertain to the implementation or use of the technology described in this document or the extent to which any license under such rights might or might not be available; neither does it represent that it has made any effort to identify any such rights. Information on the IETF's procedures with respect to rights in standards-track and standards-related documentation can be found in BCP-11. Copies of claims of rights made available for publication and any assurances of licenses to be made available, or the result of an attempt made to obtain a general license or permission for the use of such proprietary rights by implementors or users of this specification can be obtained from the IETF Secretariat.

The IETF invites any interested party to bring to its attention any copyrights, patents or patent applications, or other proprietary rights which may cover technology that may be required to practice this standard. Please address the information to the IETF Executive Director.

9. Security Considerations

There are a number of management objects defined in this MIB module with a MAX-ACCESS clause of read-write. Such objects may be considered sensitive or vulnerable in some network environments. The support for SET operations in a non-secure environment without proper protection can have a negative effect on network operations.

Setting the following object to incorrect values can result in improper operation of the PSE, including the possibility that the PD does not receive power from the PSE port:

```
pethPsePortAdminEnable
pethPsePortPowerPairs
pethPsePortPowerPriority
pethPsePortType
```

Setting the following objects to incorrect values can result in an excessive number of traps being sent to network management stations:

```
pethMainPseUsageThreshold
pethNotificationControlEnable
```

Some of the readable objects in this MIB module (i.e., objects with a MAX-ACCESS other than not-accessible) may be considered sensitive or vulnerable in some network environments. These are:

```
pethPsePortPowerPairsControlAbility
pethPsePortPowerPriority
pethPsePortPowerClassifications
```

It is thus important to control even GET and/or NOTIFY access to these objects and possibly to even encrypt their values when sending them over the network via SNMP.

SNMP versions prior to SNMPv3 did not include adequate security. Even if the network itself is secure (for example by using IPSec), even then, there is no control as to who on the secure network is allowed to access and GET/SET (read/change/create/delete) the objects in this MIB module.

It is RECOMMENDED that implementers consider the security features as provided by the SNMPv3 framework (see [RFC3410], section 8), including full support for the SNMPv3 cryptographic mechanisms (for authentication and privacy).

Further, deployment of SNMP versions prior to SNMPv3 is NOT RECOMMENDED. Instead, it is RECOMMENDED to deploy SNMPv3 and to enable cryptographic security. It is then a customer/operator responsibility to ensure that the SNMP entity giving access to an instance of this MIB module is properly configured to give access to the objects only to those principals (users) that have legitimate rights to indeed GET or SET (change/create/delete) them.

10. Authors' Addresses

Avi Berger
PowerDsine Inc.
1, Hanagar St., P.O. Box 7220
Hod Hasharon 45421,
Israel

Phone: +972-9-7755100 Ext 307
Fax: +972-9-7755120
EMail: avib@PowerDsine.com

Dan Romascanu
Avaya
Atidim Technology Park, Bldg. #3
Tel Aviv, 61131
Israel

Phone: +972-3-645-8414
EMail: dromasca@avaya.com

11. Full Copyright Statement

Copyright (C) The Internet Society (2003). All Rights Reserved.

This document and translations of it may be copied and furnished to others, and derivative works that comment on or otherwise explain it or assist in its implementation may be prepared, copied, published and distributed, in whole or in part, without restriction of any kind, provided that the above copyright notice and this paragraph are included on all such copies and derivative works. However, this document itself may not be modified in any way, such as by removing the copyright notice or references to the Internet Society or other Internet organizations, except as needed for the purpose of developing Internet standards in which case the procedures for copyrights defined in the Internet Standards process must be followed, or as required to translate it into languages other than English.

The limited permissions granted above are perpetual and will not be revoked by the Internet Society or its successors or assignees.

This document and the information contained herein is provided on an "AS IS" basis and THE INTERNET SOCIETY AND THE INTERNET ENGINEERING TASK FORCE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY THAT THE USE OF THE INFORMATION HEREIN WILL NOT INFRINGE ANY RIGHTS OR ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Acknowledgement

Funding for the RFC Editor function is currently provided by the Internet Society.

